Digital Storage Oscilloscope

GDS-1000A-U Series

USER MANUAL GW INSTEK PART NO. 82DS1112A1EB1



ISO-9001 CERTIFIED MANUFACTURER



This manual contains proprietary information, which is protected by copyright. All rights are reserved. No part of this manual may be photocopied, reproduced or translated to another language without prior written consent of Good Will Corporation.

The information in this manual was correct at the time of printing. However, Good Will continues to improve its products and therefore reserves the right to change the specifications, equipment, and maintenance procedures at any time without notice.

Table of Contents

SAFETY I	NSTRUCTIONS	8
	Safety Symbols	8
	Safety Guidelines	9
	Power cord for the United Kingdom	12
CETTINIC		10
GETTING	1 STARTED	13
Main Featur	res	13
Panel Overv	view	15
	Front Panel	15
	Rear Panel	
	Display	
Setting up t	he Oscilloscope	20
Setting up t		
	EFERENCE	23
Menu Tree a	and Shortcuts	23
	CH1/CH2 key	24
	Cursor key 1/2	25
	Cursor key 2/2	25
	Display key	
	Autoset key	26
	Hardcopy key	26
	Help key	27
	Horizontal menu key	27
	Math key 1/2 (+/-/x)	29
	Math key 2/2 (FFT/FFT rms)	
	Measure key	
	Run/Stop key	
	Save/Recall key 1/10	32
	Save/Recall key 2/10	32
	Save/Recall key 3/10	
	Save/Recall key 4/10	
	Save/Recall key 5/10	34
	Save/Recall key 6/10	34
	Save/Recall key 7/10	35
	Save/Recall key 8/10	35
	Save/Recall key 9/10	
	Save/Recall key 10/10	
	Trigger key 1/6	

	Trigger key 2/6	
	Trigger key 3/6	38
	Trigger key 4/6	38
	Trigger key 5/6	39
	Trigger key 6/6	39
	Utility key 1/10 (Utility #1)	40
	Utility 2/10 (Utility #2)	40
	Utility key 3/10 (Utility #3)	41
	Utility key 4/10 (Hardcopy -Save All)	41
	Utility key 5/10 (Hardcopy -Save Image)	42
	Utility key 6/10 (Probe compensation)	42
	Utility key 7/10 (Go-NoGo)	43
	Utility key 8/10 (Data Logging 1/2)	43
	Utility key 9/10 (Data Logging 2/2)	44
	Utility key 10/10 (Self CAL Menu)	44
Default Setting	s	45
Puilt in Holn	-	16
Built-III Help	•••••••••••••••••••••••••••••••••••••••	40
MEASUREM	IENT	47
Basic Measure	ments	47
busic measure	Activating a channel	
	Lising Autoset	
	Running and stopping the trigger	50
	Changing the horizontal position and scale	51
	Changing the vertical position and scale	52
	Using the probe compensation signal	53
Automatic Mag	osing the probe compensation signal minimum	55 5 5
Automatic Mea		
	Measurement items	
	Automatic measurement gating	
	Automatically measuring the input signals	
Cursor Measur	ements	61
	Using the horizontal cursors	61
	Using the vertical cursors	62
Math Operation	ns	63
	Overview	63
	Adding, subtracting or multiplying signals	64
	Using the FFT function	65
Go No-Go Test	ing	
23.10 00 1000	Overview	67
	Edit: NoGo When	
	Edit: Source	
	Edit: NoGo Violation Conditions	
	Edit: Template (boundary)	
	F / //	

G≝INSTEK

	Run Go-NoGo Tests	73
Data Logging		74
00 0	Overview	74
	Edit: Source	75
	Edit: Setup Parameters	75
	Run Data logging	77
CONFIGUR	ATION	78
Acquisition		78
	Selecting the acquisition mode	78
	Selecting Delay mode	80
	Real time vs Equivalent time sampling mode	
Display		83
Display	Selecting vector or det drawing	0J
	Accumulating the waveform	
	Adjusting the display contract	ده ۸ و
	Solocting the display contrast	04 01
	Selecting the display glid	
Horizontal Viev	W	85
	Moving the waveform position horizontally	
	Selecting the horizontal scale	85
	Selecting the waveform update mode	
	Zooming the waveform horizontally	
	Viewing waveforms in the X-Y mode	88
	Horizontal Adjustment Menu	
Vertical View (Channel)	91
	Moving the waveform position vertically	91
	Selecting the vertical scale	91
	Selecting the coupling mode	91
	Expand Vertical Scale Center / Ground	92
	Inverting the waveform vertically	93
	Limiting the waveform bandwidth	94
	Probe attenuation level and type	94
Trigger		96
	Trigger type	96
	Trigger parameter	96
	Configuring Holdoff	98
	Configuring the edge trigger	99
	Configuring the video trigger	100
	Configuring the pulse width trigger	101
	Manually triggering the signal	
Remote Contro	l Interface	104
System Setting	s	105
	Viewing the system information	

	Selecting the language	105
SAVE/RECA	LL	. 107
File Structures		107
	Display image file format	107
	Waveform file format	107
	Setup file format	110
	Using the USB file utilities	111
Quick Save (Ha	rdCopy)	113
Save	,	115
	File type/source/destination	115
	Saving the panel settings	116
	Saving the waveform	117
	Saving the display image	119
	Saving all (panel settings, display image, waveform).	120
Recall		122
	File type/source/destination	122
	Recalling the default panel settings	123
	Recalling a reference waveform to the display	124
	Recalling panel settings	124
	Recalling a waveform	125
	Recall Image	127
MAINTENA	NCE	. 129
Vertical Resolu	tion Calibration	
Probe Compone	sation	120
Frobe Compens	Sation	150
FAQ		. 132
	The input signal does not appear in the display	132
	I want to remove some contents from the display	132
	The waveform does not update (frozen)	133
	The probe waveform is distorted	133
	Autoset does not catch the signal well	133
	I want to clean up the cluttered panel settings	133
	The saved display image is too dark on the backgroun	1d. 133
	The accuracy does not match the specifications	134 saved
	The oscilloscope will not allow a 21vl wavelorm to be	3aveu. 134
APPENDIX.		. 135
Luca Daulasaus	ont	125

GWINSTEK

GDS-1000A-U Series Specifications	136
Model-specific specifications	136
Common specifications	137
Probe Specifications	
GDS-1072A-U Probe	
GDS-1102A-U Probe	
GDS-1152A-U Probe	
Dimensions	141
EC Declaration of Conformity	142
INDEX	



This chapter contains important safety instructions that should be followed when operating and storing the oscilloscope. Read the following before any operation to ensure your safety and to keep the oscilloscope in the best condition.

Safety Symbols

These safety symbols may appear in this manual or on the oscilloscope.

	Warning: Identifies conditions or practices that could result in injury or loss of life.
	Caution: Identifies conditions or practices that could result in damage to the oscilloscope or to other objects or property.
<u>À</u>	DANGER High Voltage
<u>!</u>	Attention: Refer to the Manual
	Protective Conductor Terminal
	Earth (Ground) Terminal



Do not dispose electronic equipment as unsorted municipal waste. Please use a separate collection facility or contact the supplier from which this instrument was purchased.

Safety Guidelines

General Guideline	 Make sure the BNC input voltage does not exceed 300V peak.
	 Never connect a hazardous live voltage to the ground side of the BNC connectors. It might lead to fire and electric shock.
	• Do not place heavy objects on the oscilloscope.
	 Avoid severe impact or rough handling that may damage the oscilloscope.
	• Avoid discharges of static electricity on or near the oscilloscope.
	• Use only mating connectors, not bare wires, for the terminals.
	• Do not block the cooling fan vent.
	• Do not perform measurements at power sources and building installation sites (Note below).
	• The oscilloscope should only be disassembled by a qualified technician.
	(Measurement categories) EN 61010-1:2001 specifies the measurement categories and their requirements as follows. The GDS-1000A-U falls under category II.
	• Measurement category IV is for measurement performed at the source of a low-voltage installation.
	• Measurement category III is for measurement performed in a building installation.
	 Measurement category II is for measurement performed on circuits directly connected to a low voltage installation.
	 Measurement category I is for measurements performed on circuits not directly connected to Mains.

G≝INSTEK

Power Supply	• AC Input voltage: 100 ~ 240V AC, 47 ~ 63Hz		
WARNING	• The power supply voltage should not fluctuate more than 10%.		
	• Connect the protective grounding conductor of the AC power cord to an earth ground.		
Fuse	• Fuse type: T1A/250V		
WARNING	• To ensure fire protection, replace the fuse only with the specified type and rating.		
	• Disconnect the power cord before replacing the fuse.		
	• Make sure the cause of fuse blowout is fixed before replacing the fuse.		
Cleaning the oscilloscope	• Disconnect the power cord before cleaning the oscilloscope.		
	• Use a soft cloth dampened in a solution of mild detergent and water. Do not spray any liquid into the oscilloscope.		
	• Do not use chemicals containing harsh products such as benzene, toluene, xylene, and acetone.		
Operation Environment	• Location: Indoor, no direct sunlight, dust free, almost non-conductive pollution (Note below)		
	• Relative Humidity: $\leq 80\%$, 40°C or below		
	≤45%, 41°C~50°C		
	• Altitude: < 2000m		
	• Temperature: 0°C to 50°C		

	(Pollution Degree) EN 61010-1:2001 specifies pollution degrees and their requirements as follows. The oscilloscope falls under degree 2. Pollution refers to "addition of foreign matter, solid, liquid, or
	gaseous (ionized gases), that may produce a reduction of dielectric strength or surface resistivity".
	 Pollution degree 1: No pollution or only dry, non-conductive pollution occurs. The pollution has no influence.
	 Pollution degree 2: Normally only non-conductive pollution occurs. Occasionally, however, a temporary conductivity caused by condensation must be expected.
	 Pollution degree 3: Conductive pollution occurs, or dry, non- conductive pollution occurs which becomes conductive due to condensation which is expected. In such conditions, equipment is normally protected against exposure to direct sunlight, precipitation, and full wind pressure, but neither temperature nor humidity is controlled.
Storage	Location: Indoor
environment	 Storage Temperature: -10°C~60°C, no condensation-
	• Relative Humidity: 93% @ 40°C
	65% @ 41°C ~60°C
Disposal	Do not dispose this instrument as unsorted municipal waste. Please use a separate collection facility or contact the supplier from which this instrument was purchased. Please make sure discarded electrical waste is properly recycled to reduce environmental impact.

GWINSTEK

Power cord for the United Kingdom

When using the oscilloscope in the United Kingdom, make sure the power cord meets the following safety instructions.

NOTE: This lead/a	ppliance must on	ly be wired by competent persons
	HIS APPLIANCE N	MUST BE EARTHED
IMPORIANT: The v	wires in this lead	are coloured in accordance with the
following code:		
Green/ Yellow:	Earth	OE
Blue:	Neutral	
Brown:	Live (Phase)	
As the colours of the wires in main leads may not correspond with the		

As the colours of the wires in main leads may not correspond with the coloured marking identified in your plug/appliance, proceed as follows:

The wire which is coloured Green & Yellow must be connected to the Earth terminal marked with either the letter E, the earth symbol \bigoplus or coloured Green/Green & Yellow.

The wire which is coloured Blue must be connected to the terminal which is marked with the letter N or coloured Blue or Black.

The wire which is coloured Brown must be connected to the terminal marked with the letter L or P or coloured Brown or Red.

If in doubt, consult the instructions provided with the equipment or contact the supplier.

This cable/appliance should be protected by a suitably rated and approved HBC mains fuse: refer to the rating information on the equipment and/or user instructions for details. As a guide, a cable of 0.75mm² should be protected by a 3A or 5A fuse. Larger conductors would normally require 13A types, depending on the connection method used.

Any exposed wiring from a cable, plug or connection that is engaged in a live socket is extremely hazardous. If a cable or plug is deemed hazardous, turn off the mains power and remove the cable, any fuses and fuse assemblies. All hazardous wiring must be immediately destroyed and replaced in accordance to the above standard.

GETTING STARTED

The Getting started chapter introduces the oscilloscope's main features, appearance, and set up procedure.

Main Features

Model name	Frequency bandwidth	Input channels		
GDS-1072A-U	DC – 70MHz (–3dB)	2		
GDS-1102A-U	DC – 100MHz (–3dB)	2		
GDS-1152A-U	DC – 150MHz (–3dB)	2		
Performance	• 1 GS/s real-time sampling rate			
	• 25GS/s equivalent-time sampling rate			
	• 2M points record length			
	• Up to 10ns peak detection			
	• 2mV~10V vertical scale			
	• 1ns ~ 50s time scale			
Features	• 5.7 inch color TFT display			
	 Saving and recalling setups and waveforms 			
	• 27 automatic measurements			
	 Multi-language menu (12 languages) 			
	• Math operation: Add multiplication, FFT, 1	lition, Subtraction, FFT RMS		
	Data logging			
	Go-NoGo testing			
	 Edge, video, pulse width trigger 			

Compact size: (W) 310 x (D) 140 x (H) 142 mm
Probe factor from 0.1X~2000X voltage/current
USB 2.0 full-speed interface for saving and recalling data
Calibration output
External trigger input

• USB slave interface for remote control

Panel Overview

Front Panel



LCD display TFT color, 320 x 234 resolution, wide angle view LCD display.

Function keys: F1 (top) to F5 (bottom)		Activates the functions which appear in the left side of the LCD display.
Variable knob	VARIABLE	Increases or decreases values and moves to the next or previous parameter.
Acquire key	Acquire	Configures the acquisition mode (page 78).
Display key	Display	Configures the display settings (page 83).
Cursor key	Cursor	Runs cursor measurements (page 61).

(Continued on next page)

Utility key	Utility	Configures the Hardcopy function (page 113), shows the system status (page 105), selects the menu language (page 105), runs the self calibration (page 129) and configures the probe compensation signal (page 130).
Help key	Help	Shows the Help contents on the display (page 46).
Autoset key	Autoset	Automatically configures the horizontal, vertical, and trigger settings according to the input signal (page 48).
Measure key	Measure	Configures and runs automatic measurements (page 55).
Save/Recall key	Save/Recall	Saves and recalls images, waveforms, or panel settings (page 107).
Hardcopy key	Hardcopy	Stores images, waveforms, or panel settings to USB (page 113).
Run/Stop key	Run/Stop	Runs or stops triggering (page 50).
Trigger level knob		Sets the trigger level (page 96).
Trigger menu key	MENU	Configures the trigger settings (page 96).
Single trigger key	SINGLE	Selects the single triggering mode (page 103).
Trigger force key	FORCE	Acquires the input signal once regardless of the trigger condition at the time (page 103).
Horizontal menu key	MENU	Configures the horizontal view (page 85).

GWINSTEK

Horizontal position knob	$\triangleleft \bigcirc \triangleright$	Moves the waveform horizontally (page 85).
TIME/DIV knob	TIME/DIV	Selects the horizontal scale (page 85).
Vertical position knob	$\bigcirc^{\triangle}_{\nabla}$	Moves the waveform vertically (page 91).
CH1/CH2 key	CH 1	Configures the vertical scale and coupling mode for each channel (page 91).
VOLTS/DIV knob	VOLTS/DIV	Selects the vertical scale (page 91).
Input terminal	CH1	Accepts input signals: 1MΩ±2% input impedance, BNC terminal.
Ground terminal		Accepts the DUT ground lead to achieve a common ground.
MATH key	MATH	Performs math operations (page 63).
USB port		Facilitates transferring waveform data, display images, and panel settings (page 107).
Probe compensation output	≈2VЛ ()	Outputs a 2Vp-p, square signal for compensating the probe (page 130) or demonstration.
External trigger input		Accepts an external trigger signal (page 96).
Power switch	POWER LIO	Powers the oscilloscope on or off.

Rear Panel



Display

Waveform marker	Waveform positi	on Trigger stat	us Acquisition
2	(*** 0.0 ********************************		Display Type Accumulate Off Refresh Contrast + Full
Vertical status	Horizontal status	Frequency	Trigger condition
Waveforms	Channel 1: Yel	low Cha	nnel 2: Blue
Trigger status	Trig'd	A signal is bein	g triggered
	Trig?	Waiting for a tr	rigger condition
	Auto	Updating the in regardless of tr	nput signal igger conditions
	STOP	Triggering is st	opped
	For trigger set	ting details, see	page 96.
Input signal frequency	Updates the input signal frequency (the trigger source signal) in real-time.		
	"< 2Hz" Indication than the lower accurate.	ates that the sign frequency limit	nal frequency is less (2Hz) and thus not
Trigger configuration	Shows the trigger source, type, and slope. In case of the Video trigger, shows the trigger source and polarity.		
Horizontal status	Shows the channel configurations: coupling mode,		
Vertical status	vertical scale, a	and norizontal s	cale.

Setting up the Oscilloscope

Background	This section describes how to set up the oscilloscope properly including adjusting the handle, connecting a signal, adjusting the scale, and compensating the probe. Before operating the oscilloscope in a new environment, run these steps to make sure the oscilloscope is functionally stable.
Procedure	1. Pull both bases of the handle out slightly.
	2. Turn to one of the three preset positions.
	3. Connect the power cord.
	4. Press the power switch. The display will become active in approximately 10 seconds.
	5. Reset the system by recalling Save/Recall the factory settings. Press the Save/Recall key, then <i>Default Setup</i> . For details regarding the factory settings, see page 45.

- 6. Connect the probe between the Channel1 input terminal and probe compensation signal output (2Vp-p, 1kHz square wave).
- 7. Set the probe attenuation voltage to x10.



8. Press the Autoset key. A square waveform will appear in the center of the display. For details on Autoset, see page 48.





(Autoset)



10. Turn the adjustment point on the probe to flatten the square waveform edge.



11. Setting up the oscilloscope is complete. You may continue with the other operations.

Measurement: page 47 Configuration: page 78

This chapter lists the oscilloscope menu tree, operation shortcuts, built-in help coverage, and default factory settings. Use this chapter as a handy reference to access the oscilloscope functions.

Menu Tree and Shortcuts

Conventions	Examples
Normal	= Press the functional key for "Normal"
Average	= Repeatedly press the functional key for "Average"
Normal ~ Average	= Select a menu from "Normal" to "Average" and press its functionality key
Normal \rightarrow VAR \bigcirc	= Press the functionality key for "Normal", and then use the Variable knob

Acquire key



Select acquisition mode

Normal ~ Peak-Detect

Select average number

Average₽

Turn Delay on/off

Delay On₽

CH1/CH2 key



Turn channel on/off CH 1/2 ← Select coupling mode Coupling ← Invert waveform Invert ↓ Turn bandwidth limit on/off BW Limit ← Select probe type Voltage ← Current Select probe attenuation VAR (0.1x~2000x) (1-2-5 step) Expand ↓

Cursor key 1/2



Turn cursor on/off

Cursor₽

Move X1 cursor

 $X1 \rightarrow VAR O$

Move X2 cursor

 $X2 \rightarrow VAR O$

Move both X1 and X2 cursor

 $X1X2 \rightarrow VAR \bigcirc$

Switch to Y cursor

X↔Y

Cursor key 2/2



X↔Y

Display key



Autoset key



Hardcopy key



 \rightarrow See Utility key (page 40)

Help key

Help	Turn help mode on/off
	Help₽

Horizontal menu key



Select window mode	Window \rightarrow TIME/DIV O
Zoom in window mode	Window Zoom
Select window roll mode	Roll
Select XY mode	XY
Toggle adjustment mode	H Pos Adj₽
Reset horizontal marker	Reset
Set Horizontal marker/delete horizontal marker.	HOR $\bigcirc \rightarrow$ Set/Clear
Navigate to previous horizontal marker.	Previous

Navigate to next horizontal Next marker.

Math key 1/2 (+/-/x)



Math key 2/2 (FFT/FFT rms)



Math on/off

Math₽

Select math operation type (+/-/x/FFT/FFT rms)

Operation₽

Select FFT source channel

Source₽

Select FFT window

Window₽

Select FFT result position

Vertical \rightarrow VAR \bigcirc

Select vertical scale

Vertical→VOLTS/DIV〇

Select vertical units

Vertical₽

Select Zoom level

Zoom(X)→VAR 〇

Select Horizontal position

Zoom(Hz)→VAR 〇

Measure key



Run/Stop key



Save/Recall key 1/10



Save/Recall key 2/10



File Utilities

Save/Recall key 3/10



Select other menu Recall Waveform ← Select waveform source Source ←→VAR Select waveform destination Destination→VAR Recall waveform Recall Go to USB file utilities File Utilities

Save/Recall key 4/10



Select other menu

Recall Image₽

Turn reference image on/off

Ref image ←

Recall waveform

Recall

Go to USB file utilities

File Utilities

Save/Recall key 5/10



Select other menu
Display Refs.₽
Turn ref. waveform A on/off
Ref.A
Turn ref. waveform B on/off
_{Ref.B} ₽

Save/Recall key 6/10



Select other menu	
Save Setup₽	
Select destination	
Destination \frown VAR	0
Save setup	
Save	
Go to USB file utiliti	es
File Utilities	

Save/Recall key 7/10



Select other menu Save Waveform ← Select source Source ← →VAR Select destination Destination ← →VAR Save waveform Save Go to USB file utilities File Utilities

Save/Recall key 8/10



Select other menu

Save Image ←

Turn on/off ink saver

Ink Saver₽

Save image

Save

Go to USB file utilities

File Utilities

Save/Recall key 9/10



Select other menu
Save All
Turn on/off ink saver
Ink Saver 🕶
Select destination
Destination $\overleftarrow{\leftarrow} \rightarrow VAR \bigcirc$
Save all
Save
Go to USB file utilities
File Utilities

Save/Recall key 10/10



Select file/folder

 $VAR \bigcirc \rightarrow Select$

Create or rename folder/file

New Folder/Rename

VAR \bigcirc Enter character / Backspace / Save / Previous menu

Delete folder/file

Delete

Go to previous menu

Previous menu
Trigger key 1/6



Trigger key 2/6

Coupling Mode Auto



Trigger key 3/6



Select edge trigger type

Edge₽

Select trigger source

Source₽

Go to slope/coupling menu (page 39)

Slope/Coupling

Select trigger mode

Mode₽

Trigger key 4/6



Select pulse trigger type

Type₽

Select trigger source

Source₽

Select pulse trigger condition and pulse width

When $\overrightarrow{\leftarrow}$ \rightarrow VAR \bigcirc

Go to slope/coupling menu (page 39)

Slope/Coupling

Select trigger mode

Mode₽

Trigger key 5/6



Trigger key 6/6



Utility key 1/10 (Utility #1)



Go to hardcopy menu Hardcopy Go to probe compensation menu ProbeComp Select language Language Show system information System Info. Go to the next Utility menu More

Utility 2/10 (Utility #2)



Go to the Go-NoGo menu

Go-NoGo

Set the NoGo conditions to inside /outside /limits

No Go When ₽

Go to the Data Logging Menu

Data Logging

Go to the next Utility menu

More

Utility key 3/10 (Utility #3)



Utility key 4/10 (Hardcopy -Save All)



Select Hardcopy function Function Turn on/off Ink saver Ink Saver Set the memory length Mem Leng Change CSV format CSV Format Go to previous menu Previous Menu Previous Menu

Utility key 5/10 (Hardcopy -Save Image)



Select Hardcopy function Function ← Turn on/off Inksaver Ink Saver ← Go to previous menu Previous Menu ←

Utility key 6/10 (Probe compensation)



Select probe compensation signal Wave Type Set frequency for square wave Frequency→VAR Set duty cycle for square wave Duty Cycle→VAR Go to previous menu

Previous Menu

Utility key 7/10 (Go-NoGo)



Switch between templates Template ← Select the template source Source ← Set the tolerance (% or Divisions) Tolerance ← →VAR Save the template Save & Create Go back to previous menu

Utility key 8/10 (Data Logging 1/2)



Turn Data Logging On/Off Data logging ← Set the logging source Source ← Go to the Data Logging Edit menu Setup Go to the File Utilities menu File Utilities Go back to previous menu

Previous Menu

Previous Menu

Utility key 9/10 (Data Logging 2/2)



Save the logs as waveform data or as image files

Set the logging interval

Interval \rightarrow VAR \bigcirc

Set the duration of the record log

Duration \rightarrow VAR \bigcirc

Go back to previous menu

Previous Menu

Utility key 10/10 (Self CAL Menu)



Default Settings

Here are the factory installed panel settings which appear when pressing the Save/Recall key \rightarrow *Default Setup*.

Save/Recall Default Setup

Acquisition	Mode: Normal				
Channel	Scale: 2V/Div	Invert: Off			
	Coupling: DC	Probe attenuation voltage: x1			
	BW limit: Off	Channel 1 & 2: On			
Cursor	Source: CH1	Cursor: Off			
Display	Type: Vectors Grid: Full	Accumulate: Off			
Horizontal	Scale: 2.5us/Div	Mode: Main Timebase			
	H Pos Adj: Fine	Hor Pos: 0			
Math	Type: + (Add)	Position: 0.00 Div			
	Unit/Div: 2V				
Measure	Item: Vpp, Vavg, Frequer Time	ncy, Duty Cycle, Rise			
Trigger	Type: Edge	Source: Channel1			
	Mode: Auto	Slope:			
	Coupling: DC	Rejection: Off			
	Noise Rejection: Off				
Utility	Hardcopy: SaveImage, InkSaver On	ProbeComp: Square wave, 1k, 50% duty cycle			
Go-NoGo	Go-NoGo: Off	Source: CH1			
	When:	Violating: Stop			
(Continued)					

45

Data Logging	Data logging: Off	Source: CH1
	Setup: Waveform	Interval: 2 secs
	Duration: 5 mins	

Built-in Help



The Measurement chapter describes how to properly observe a signal using the oscilloscope's basic functions, and how to observe a signal in a detailed manner using some of the advanced functions such as:

Automatic measurements, cursor measurements, and math operations.

Basic Measurements

This section describes the basic operations required in capturing and viewing an input signal. For more detailed operations, see the following chapters.

- Measurements \rightarrow from page 47
- Configuration \rightarrow from page 78

Activating a channel

Activating a channel	To activate an input channel, press the Channel key, CH1 or CH2. The channel indicator appears at the left side of the display and the channel icon	CH 1 or	CH 2
	changes accordingly.		

(Continued on next page)



De-activating a To de-activate the channel, press the Channel key twice (once if the channel menu is already selected).

Using Autoset

Background	The Autoset function automatically configures the panel settings to the best viewing conditions, in the following way.		
	Selecting the horizontal scale		
	Positioning the waveform horizontally		
	Selecting the vertical scale		
	Positioning the waveform vertically		
	Selecting the trigger source channel		
	Activating the channels		
	Autoset can be configured into two types of modes, AC Priority Mode or Fit Screen Mode.		
	AC Priority mode will scale the waveform to the screen removing any DC component.		
	Fit Screen Mode will fit the waveform to the best scale, including any DC components (offset).		

Autoset

- Procedure 1. Connect the input signal to the oscilloscope and press the Autoset key.
 - 2. The waveform(s) appears in the center of the display.





Limitation

Autoset does not work in the following situation.

- Input signal frequency less than 20Hz
- Input signal amplitude less than 30mV

Running and stopping the trigger

Background In the trigger Run mode, the oscilloscope constantly searches for a trigger condition and updates the signal onto the display when the condition is met.

> In the trigger Stop mode, the oscilloscope stops triggering and thus the last acquired waveforms stay in the display. The trigger icon at the top of the display changes into Stop mode.

Pressing the Trigger Run/Stop key switches between the Run and Stop mode.





Waveforms can be moved or scaled in both the
Run and Stop mode. For details, see page 85
(Horizontal position/scale) and page 91 (Vertical
position/scale).

Changing the horizontal position and scale

For more detailed configurations, see page 85.

Setting the horizontal position	The horizontal position knob moves the waveform left or right. The position indicator moves along with the waveform and the distance from the center point is displayed as the offset in the upper side of the display.				
	Horizontal offset				
	Hor.MENU Main Position indicator Window Zoom Roll XY G=S06w/ G258ws G11.89763kHz EDGE_fDC EDGE_FDC				
Selecting the horizontal scale	To select the timebase (scale), turn TIME/DIV the TIME/DIV knob; left (slow) or right (fast).				
	Range 1ns/Div ~ 10s/Div, 1-2.5-5 increment				



Changing the vertical position and scale

For more detailed configuration, see page 91.

Set vertical position	To move the waveform up or down, turn the vertical position $\bigcirc \bigcirc \bigtriangledown$ knob for each channel.		
	As the waveform moves, the vertical position of the cursor appears at the bottom left corner of the display.		
	Run/Stop mode The waveform can be moved vertically in both Run and Stop mode.		
Select vertical scale	To change the vertical scale, VOLTS/DIV turn the VOLTS/DIV knob; left (down) or right (up).		
	Range $2mV/Div \sim 10V/Div$, 1-2-5 increments		
	The vertical scale indicator for each channel on the bottom left of the display changes accordingly.		

11 1 1				• •
l Ising the	nrohe	com	nensation	signal
O Jing the	probe	com	pensation	JIGHU

Background	This section introduces how to use the probe compensation signal for general usage, in case the DUT signal is not available or to get a second signal for comparison. For probe compensation details, see page 130.		
Ĺ	Note: The frequency accuracy and duty factor are not guaranteed. Therefore the signal should not be used for reference purposes.		
Waveform type	лл	Square waveform used compensation. 1k ~ 10 95%.	d for probe 00kHz, 5% ~
	JUL	Demonstration signal the effects of peak dete 78 for peak detection r	for showing ection. See page mode details.

View the probe compensation waveform 1. Connect the probe between the compensation signal output and Channel input.



- 2. Press the Utility key.
- 3. Press ProbeComp.



GWINSTEK



compensation

Automatic Measurements

The automatic measurement function measures input signal attributes and updates them in the display. Up to 5 automatic measurement items can be updated at any one time on the side menus. All automatic measurement types can be displayed on screen if necessary.

Measurement items

Overview	Voltage type	Ti	me type	Delay type
	Vpp Vmax Vmin Vamp Vhi Vlo Vavg Vrms ROVShoot FOVShoot RPREShoot FPREShoot		requency eriod iseTime allTime Vidth Vidth utycycle	FRR FRF FFF FFF FFF LRR LFF LFF LFF
Voltage measurement items	Vpp	<u> </u>	Difference betw and negative pe (=Vmax – Vmir	een positive ak voltage 1)
	Vmax		Positive peak vo	oltage.
	Vmin		Negative peak v	voltage.
	Vamp	<u>↓</u>	Difference betw high and global (=Vhi – Vlo)	een global low voltage
	Vhi	╪ _┙ ┍╴	Global high vol	tage.

	Vlo	ŢŢ	Global low voltage.
	Vavg	t AA	Averaged voltage of the first cycle.
	Vrms	IVV	RMS (root mean square) voltage.
	ROVShoot	*_~~	Rise overshoot voltage.
	FOVShoot	• /~-	Fall overshoot voltage.
	RPREShoot		Rise preshoot voltage.
	FPREShoot	/¥	Fall preshoot voltage.
Time measurement items	Freq	ţ_ţ	Frequency of the waveform.
	Period	ŢŢ	Waveform cycle time (=1/Freq).
	Risetime	_∕₊	Rising time of the pulse (~90%).
	Falltime		Falling time of the pulse (~10%).
	+Width	<u> </u>	Positive pulse width.
	–Width	Ţ	Negative pulse width.
	Duty Cycle	ŢIJ	Ratio of signal pulse compared with whole cycle =100x (Pulse Width/Cycle)
Delay measurement items	FRR	┹ Ţ	Time between: Source 1 first rising edge and Source 2 first rising edge

FRF	≝ी ĴŦĹ _ĸ ſĨ	Time between: Source 1 first rising edge and Source 2 first falling edge
FFR	Ŀ Ŀ Ŀ	Time between: Source 1 first falling edge and Source 2 first rising edge
FFF	」 ╕ _╕ _╲ ╷҇	Time between: Source 1 first falling edge and Source 2 first falling edge
LRR	≝ा _ा_ू±ो	Time between: Source 1 first rising edge and Source 2 last rising edge
LRF	≝ <u>∩</u> _∩Fi	Time between: Source 1 first rising edge and Source 2 last falling edge
LFR	_╕ _᠋᠋ᠧᢩᢣ᠋ᢆ᠋	Time between: Source 1 first falling edge and Source 2 last rising edge
LFF	_]_]]_	Time between: Source 1 first falling edge and Source 2 last falling edge

Automatic measurement gating

Background	Automatic measurements can be restricted to a specific area (gating). When cursors are turned on, the area between the cursors is used for automatic measurements. When cursors are turned off, measurements are derived from all the points that are displayed on screen.
Turn gating on	1. Turn on cursors to enable page 61

gated automatic gated automatic gated automatic

2. Press the Measure key.

Mea	sure
	$ \longrightarrow $
L	IJ

3. The measurement results appear on the menu bar, constantly updated. All measurements are derived from the cursor positions. See *Automatically measuring the input signals* for more details (page 58).



Turn gating off 4. Turn off cursors to turn off page 61 gated automatic measurements.

Automatically measuring the input signals

- Viewing the 1. Press the Measure key.
 - 2. The measurement results appear on the menu bar, constantly updated. 5 measurement slots (F1 to F5) can be customized.

Voltage

Vpp



Editing a measurement item 3. Press the corresponding menu key (*F1~F5*) to select the measurement slot to be edited.

4. The editing menu appears



Change measurement item	5.	Use the Var select a diffe measureme	iable knob to erent nt item.		
Change measurement source	6.	Press <i>Source 1</i> repeatedly to change Source1 from CH1 to CH2 or MATH.		Source 1 CH1	
		Range	CH1, 2, Math		

7. Press *Source* 2 repeatedly to change the channel for Source2.



Range CH1, 2, Math

View all measurements

8. Press *F3* to view all measurement items.



9. All the measurements appear in the center of the screen.

Select Me	<pre>>>* 0.000s * asurement</pre>	Trigde j	Cource 1
Voltage Vupp Umax Umin Uamp Uhi Ulo Uavg Urms ROUShoc FOUShoc RPRESho	Time Frequency Period RiseTime FallTime +Width -Width DutyCycle t t t ot	Delay DelayFRR DelayFFR DelayFFR DelayFR DelayLRR DelayLRF DelayLFR DelayLFF	CH 1 Source 2 CH 2 Voltage Vpp

10. Press F3 again to return.

Note: All the editing operations can still be performed when viewing all the measurement items.

11. Press *Previous Menu* to confirm the item selection and to go back to the measurement results view.



Cursor Measurements

Cursor lines, horizontal or vertical, show the precise position of the input waveforms or the math operation results. The horizontal cursors can track time, voltage/current* and frequency, whilst the vertical cursors can track voltage/current*. All measurements are updated in real-time. *probe type dependant (page 94).

Using the horizontal cursors

Procedure	1. Pres curs disp	s the Cursor key. The ors appear in the lay.	Cursor		
	2. Pres hori	as $X \leftrightarrow Y$ to select the zontal (X1&X2) cursor.	X↔Y		
	3. Press <i>Source</i> repeatedly to select the source channel. CH1				
	Rar	nge CH1, 2, MATH			
	4. The the	cursor measurement res menu, F2 to F4.	ults will appear in		
Parameters	XI	Time position of the left zero)	cursor. (relative to		
	X2	Time position of the right to zero)	ht cursor. (relative		
	X1X2	The difference between	the X1 and X2.		
	Δ : us	The time difference betw	ween X1 and X2.		
	f: Hz	The time difference configuration frequency.	verted to		
	V/A	The voltage/current dif and X2.	ference from X1		

	M1:dB	Position of the left cursor in dB.			
	M2:dB	Position of the right cursor in dB.			
	Δ : dB	The dB difference between M1 and M			
	Div:	The frequency per divis	ion.		
Moving the horizontal cursors	To mov X1 and knob.	e the left cursor, press then use the Variable	X1 -5.000uS 0.000uV		
	To mov X2 and knob.	e the right cursor, press then use the Variable	X2 5.000uS 0.000uV		
	To mov press X Variabl	e both cursors at once, 1X2 and then use the e knob.	X1X2 ∆: 10.00uS f: 100.0kHz 0.000uV		
Remove cursors	Press C onscree	ursor to remove the n cursors.	Cursor		

Using the vertical cursors

Procedure	1. Pr	ess the Cursor key.	Cursor
	2. Prove	ess $X \leftrightarrow Y$ to select the rtical (Y1&Y2) cursor.	X↔Y
	3. Prosel	ess <i>Source</i> repeatedly to ect the source channel.	CH1
	R	ange CH1, 2, MATH	Ι
	4. Th the	e cursor measurement re e menu.	sults will appear in
Parameters	Y1	Voltage level of the u	pper cursor
	Y2	Voltage level of the lo	ower cursor

	Y1Y2	The difference between the upper and lower cursor			
	V/A	The voltage/current d	ifference (Y1-Y2).		
Moving the vertical cursors	To move press Y1 Variable	the upper cursor, and then use the knob.	Y1 123.4mV		
	To move press Y2 Variable	the lower cursor, and then use the knob.	Y2 12.9mV		
	To move press Y1 Variable	both cursors at once, Y2 and then use the knob.	Y1Y2 10.5mV		
Remove cursors	Press Cu onscreen	rsor to remove the cursors.	Cursor		

Math Operations

The Math operations can add, subtract, multiply or perform FFT/FFT RMS on the input waveforms. The resulted waveform can be measured using the cursors, and saved or recalled just like normal input signals.

Overview	
Addition (+)	Adds the amplitude of CH1 & CH2 signals.
Subtraction (–)	Extracts the amplitude difference between CH1 & CH2.
Multiplication (×)	Multiplies CH1 and CH2.
FFT	Performs a FFT calculation on a signal. Four types of FFT windows are available: Hanning, Flattop, Rectangular, and Blackman.

FFT RMS	Performs a FFT RMS calculation on a signal. RMS is similar to FFT, however the amplitude is calculated as RMS and not dB. Four types of FFT windows are available: Hanning, Flattop, Rectangular, and Blackman.			
Hanning FFT	Frequency resolution	Good		
window	Amplitude resolution	Not good		
	Suitable for	Frequency measurement on periodic waveforms		
Flattop FFT	Frequency resolution	Not good		
window	Amplitude resolution	Good		
	Suitable for	Amplitude measurement on periodic waveforms		
Rectangular FFT	Frequency resolution	Very good		
window	Amplitude resolution	Bad		
	Suitable for	Single-shot phenomenon (this mode is the same as having no window at all)		
Blackman FFT	Frequency resolution	Bad		
window	Amplitude resolution	Very good		
	Suitable for	Amplitude measurement on periodic waveforms		

Adding, subtracting or multiplying signals

Procedure	1.	Activate both CH1 and CH2.	CH 1 CH 2
	2.	Press the Math key.	MATH

GWINSTEK

Operation

CH1+CH2

Unit/Div

2V

Position

0.00 Div

MATH

VARIABLE

- 3. Press *Operation* repeatedly to select addition (+), subtraction (-) or multiplication (×).
- 4. The math measurement result appears in the display.
- 5. To move the math result vertically, use the Variable knob. The position will be displayed in *Position*.
- 6. To clear the math result from the display, press the Math key again.





- 5. The FFT result appears. The horizontal scale changes from time to frequency, and the vertical scale from voltage to dB or RMS.
- 6. To move the FFT waveform vertically, press *Vertical* repeatedly until Div is selected. Use the Variable knob to change the vertical scale.





Range

-12.00 Div ~ +12.00 Div

7. To select the vertical scale of an *FFT waveform*, press *Vertical* repeatedly until dB is selected. Use the Variable knob to change the vertical scale.





Range 1, 2

1, 2, 5, 10, 20 dB/Div

8. To select the vertical scale of an *FFT rms waveform*, use the VOLTS/DIV knob to change the vertical scale. The scale will be shown in the *Vertical* soft-key.



Range Volts/Div

 To zoom in on the FFT/FFT rms waveform, press Zoom repeatedly until X is selected. Use the Variable knob to change the Zoom level.





Range 1/2/5/10/20X

10. To move the FFT/FFT rms waveform horizontally, press *Zoom* repeatedly until Hz is selected. Use the Variable knob to change the horizontal position.



Range $0\sim 50.000 MHz$

11. To clear the FFT result from the display, press the Math key again.



Go No-Go Testing

Overview

Background	Go-NoGo testing checks if a waveform conforms to a user-specified maximum and minimum boundary (template). The testing can be set to stop or continue each time the template has or has not been violated by the input waveform.			
Settings	Item	Default	Details	
	NoGo criteria: When inside or outside the boundary	Inside	Page 68	
	Source	Channel 1	Page 68	
	Test continue or stop when NoGo occurs	Stop	Page 69	
	Boundary (template) – selects the minimum and maximum boundaries (template) from a single waveform	Auto (0.4%)	Page 69	
	Run Tests		Page 73	

Edit: NoGo When

Procedure	1.	Press the Utilit	y key.	Utility
	2.	Press the More	key.	More ►
	3.	Press <i>No Go When</i> repeatedly to select the NoGo conditions.		No Go When
			NoGo when tl inside the bou	he waveform is Indary (template)
			NoGo when tl outside of the (template)	ne waveform is boundary

Edit: Source

Procedure	1. Press the Utility key.	Utility
	2. Press the <i>More</i> key.	More
	3. Press the Go-NoGo Menu key.	Go-NoGo Menu
	 Press <i>Source</i> repeatedly to select the source channel (CH1 or CH2). 	Source CH1

Edit: NoGo Violation Conditions

Procedure	1.	Press the Uti	ility key.	Utility
	2.	Press the Ma	vre key.	More ►
	3.	Press the Gokey.	-NoGo Menu	Go-NoGo Menu
	4.	Press Violatia select the No	<i>ng</i> repeatedly to Go conditions.	Violating Stop
		Stop	Stops the test will conditions have	hen the NoGo been met.
		Continue	The tests continue NoGo condition	ue even when the s have been met.

Edit: Template (boundary)

Background	The NoGo template sets the upper and lower amplitude boundary. Two methods are available: Min/Max and Auto.			
	Min/Max	Selects the upper boundary (Max) and lower boundary (Min) as separate waveforms, from the internal memory. The upper boundary is saved to Ref A, the lower boundary is saved to Ref. B.		
		Advantage: The template shape and distance (allowance) between the source signal are fully customizable.		

		Disadvantag (templates) h internally pri	Disadvantage: The waveforms (templates) have to be stored internally prior to this selection. Creates the upper and lower boundary (template) from the source signal, not from an internally stored waveform.	
	Aut	o Creates the u boundary (te source signal internally stc		
		Advantage: N waveforms p	No need to store the rior to this selection.	
		Disadvantag is proportion signal. The d between the upper and lo same.	e: The template shape al to the source istance (allowance) source signal and the wer template is the	
Max/Mix	1. The Ensu disp	The template is based on the source signal. Ensure the source signal appears on the display.		
	2. Pres	s the Utility key.	Utility	
	3. Pres	is the <i>More</i> key.	More ►	
	4. Pres key.	s the Go-NoGo Menu	Go-NoGo Menu	
	5. Pres	s the <i>Template Edit</i> key	7. Template Edit	
	6. Pres selec lowe	s <i>Template</i> repeatedly ct the upper (Max) or er (Min) boundaries.	to Template Max	

7. Press *Source* and use the Variable knob to select the waveform template.





- Max Waveform A: Ref A, W01~W15
- Min
- Waveform B: Ref B, W01~W15
- 8. Press *Position* and use the Variable knob to set the waveform amplitude.



VARIABLE



- 9. Repeat steps 5-7 for the other template setting (Max or Min).
- 10. When both Max and Min templates have been configured, press *Save & Create* to save the templates.





G≝INSTEK

Auto	1.	The template is based on the source signal. Ensure the source signal appears on the display.		
	2.	Press the Utility key.	Utility	
	3.	Press the <i>More</i> key.	More ►	
	4.	Press the Go-NoGo Menu key.	Go-NoGo Menu	
	5.	Press the <i>Template Edit</i> key.	Edit	
	6.	Press <i>Template</i> repeatedly to select the Auto template.	Template Auto	
	7.	Press <i>Source</i> and use the Variable knob to select the template source.	CH1	
			VARIABLE	
		Source CH1, CH2		
	8.	Press <i>Tolerance</i> repeatedly to choose the tolerance units, % or Div. Use the Variable knob to set the tolerance. The tolerance is for both the horizontal and vertical axis.	Tolerance 0.4% VARIABLE Image: Constraint of the second	
		% 0.4% ~ 40.0%		
Div

- $0.04 \text{ Div} \sim 4.0 \text{ Div}$
- 9. When the Auto template has been configured, press *Save* & *Create* to save the template.

Save & Create



Run Go-NoGo Tests



Ensure the source signal and boundary templates appear on the screen.

Go-NoGo

On

- 4. Press *Go-NoGo*. The test starts and stops according to the conditions set on page 68, 69. To stop the test that has already started, press *Go-NoGo* again.
- 5. The test results appear in the Ratio soft-key. The numerator denotes the total number of failed tests. The denominator denotes the total number of tests.



Numerator	Number of	"failed"	tests.

Denominator Total number of tests.

Data Logging

Overview

Background	The Data logging function allows you to log data or a screen image over timed intervals for up to 100 hours to a USB flash drive.
	The data or images are stored to a USB flash drive in a directory named LogXXXX. LogXXXX is incremented each time the data logging function is used.
	The files saved in the LogXXXX directory are named DSXXXX.CSV, or DSXXXX.BMP for data or image files, respectively. At each timed interval data or an image file is saved and the file number incremented. For example, DS0000 is the first logged data, DS0001 is the second and so on.

Edit: Source

Procedure	1. Press	the Utility key.	
	2. Press	the <i>More</i> key.	More
	3. Press key.	the Data logging Menu	Data logging Menu
	4. Press select (CH1	<i>Source</i> repeatedly to the source channel or CH2).	Source CH1

Edit: Setup Parameters



- 5. Press *Save* repeatedly to log data or screen images.
- 6. Press *Interval* and use the Variable knob to select the interval time.





VARIABLE



Interval2 secs~ 2min (duration = 5 min)time2 secs~ 5 min (duration 5~ 30 min)

 $2 \text{ secs} \sim 30 \text{ min} (\text{duration } 30 + \text{min})$

7. Press *Duration* and use the Variable knob to set the duration time.



VARIABLE





8. Press Previous menu to return to the Data logging menu. Data logging is now ready to begin.



G≝INSTEK

Run Data logging

Background	Ensure the data source (page 75) and data logging setup has been set (page 75).			
Procedure	1.	Insert a USB flash drive into the USB front panel port.		
	2.	Press the Utility key.		
	3.	Press the <i>More</i> key.	More ►	
	4.	Press the <i>Data logging Menu</i> key.	Data logging Menu	
	5.	Press <i>Data logging</i> to turn data logging On. Data/image files start logging to the USB flash drive automatically. To stop the Data logging, press the <i>Data logging</i> key again.	Data logging On	



The Configuration chapter describes how to configure panel settings to make measurements and observations suited to the application needs.

Acquisition

The acquisition process samples the analog input signals and converts them into digital format for internal processing. You may select the normal, average, or peak detect acquisition mode.

Selecting the acquisition mode

Procedure	1. Press the Acquire key.	Acquire
	2. Select the acquisition mode between <i>Normal, Average</i> and <i>Peak Detect</i> .	Normal Average
		Peak Detect
Range	Normal All of the acquired	data is used to

draw the waveform.

	Average Peak detect		Multiple data is averaged to form a waveform. This mode is useful for drawing a noise-free waveform. To select the number, press <i>Average</i> repeatedly.	
			Average number: 2, 256	4, 8, 16, 32, 64, 128,
			To activate the Peak detect mode, press <i>Peak-Detect</i> . Only the minimum and maximum value pairs for each acquisition interval (bucket) are used. This mode is useful for catching abnormal glitches in a signal.	
Peak detect effect using the probe comp. waveform	ect 1. One of the compense m can dem detection probe to compense 2. Press the		he probe sation waveforms onstrate the peak n mode. Connect the the probe sation output.	≈2VЛ ()
			e Utility key.	Utility
3. Pre		Press Pro	obeComp.	ProbeComp Menu
	4.	Press Wa the Jur	<i>we Type</i> and select waveform.	Wave Type
	5.	Press the oscillosc wavefor the displ	e Autoset key. The ope positions the m in the center of lay.	(Autoset)
	6.	Press the	e Acquire key.	Acquire



Selecting Delay mode

Background	When delay time is ON, the displayed output is delayed for a defined amount of time from the trigger point. Using the delay function is useful for observing an area of the waveform that occurs some time after the trigger point.
Delay On	With Delay On the expansion point and trigger point become separated by the amount of delay time. As the delay time is increased the trigger point moves left from the expansion point. When the horizontal scale is adjusted, the waveform expands from the expansion point, not the trigger point.

GWINSTEK



With Delay Off the expansion point and trigger point are always in the same position. Thus when the horizontal scale is adjusted, the waveform expands from the trigger point.





Delay Off

- 1. Press the Acquire key.
- 2. Press *Delay* On/Off to toggle Delay On/Off.
- 3. Use the Horizontal Position knob to increase or decrease the delay time when Delay is set to On.
- 4. Adjust the horizontal scale to zoom into the waveform.





Acquire



Real time vs Equivalent time sampling mode

Background	The oscilloscope automatically switches between two sampling modes, Real-time and Equivalent- time, according to the number of active channels and sampling rate.
Real-time sampling	Once sampled data is used to reconstruct a single waveform. Short-time events might get lost if the sampling rate gets too high. This mode is used when the sampling rate is relatively low (1GSa/s or lower).
Equivalent-time sampling	Multiple numbers of sampled data are accumulated to reconstruct a single waveform. ETS restores more waveform detail but takes longer to update the waveform. This mode is used when the sampling rate becomes higher than 1GSa/s. The maximum equivalent-time sampling rate is 25GSa/s.

Display

The Display section describes how to configure the display settings: drawing type, waveform accumulation, contrast adjustment, and grid settings.

Selecting vector or dot drawing

Procedure	1. Press th	he Display key.	Display
	2. Press 7 select t drawir	<i>Type</i> repeatedly to he waveform ng.	Type Vectors
Types	Dots	Only the sample	ed dots are displayed.
	Vectors	The sampled do lines.	ts are connected by

Accumulating the waveform

Background	Accumulation preserves the old waveform drawings and overwrites new waveforms on top of it. It is useful for observing waveform variation.		
Procedure	1. Press the Display key.	Display	
	2. Press <i>Accumulate</i> to turn on the waveform accumulation.	Accumulate On	
	3. To clear the accumulation and start it over (refresh), press <i>Refresh</i> .	Refresh	

GWINSTEK

Example



Adjusting the display contrast



Horizontal View

The Horizontal view section describes how to configure the horizontal scale, position, waveform update mode, window zoom, and X-Y mode.

Moving the	waveform position horizon	itally
Procedure	The horizontal position kr moves the waveform left or right. The position indicat the top of the display show center and current position	$\begin{array}{c} \text{nob} \\ \text{or} \\ \text{or at} \\ \text{ws the} \\ \text{n.} \end{array}$
	Center position →→ Ø.000s	Moving right →→ -92.00us

Selecting the horizontal scale

Select horizontal scale	To select the turn the TIN (slow) or rig	e timebase (scale), ⁄IE/DIV knob; left ght (fast).	TIME/DIV
	Range	1ns/Div ~ 50s/Div,	1-2.5-5-10 increment

The timebase indicator at the bottom of the display updates the current horizontal scale.



Selecting the waveform update mode

Background	The display update mode is switched automatically or manually according to the horizontal scale.		
Main mode	Updates the whole displayed waveform at once. The main mode is automatically selected when the horizontal scale (timebase) is fast.		
	Horizontal scale	≤100ms/div	
	Trigger	All modes ava	ilable
Roll mode	Updates and moves the waveform gradually from the right side of the display to the left. The Roll mode is automatically selected when the horizontal scale (timebase) is 50ms or slower.		
	When in the Roll mode, an indicator appears at bottom of the display. When in roll mode the record length is 2M (1 channel) or 1M (2 channe		
	Main moo	le	Roll mode
	itiii		D 50ms Roll
	Timebase	≥50ms/div (≤2	1.25MS/s)
	Trigger	Auto mode on	ly
Selecting the Roll mode manually	1. Press the Hor key.	izontal menu	MENU
	2. Press <i>Roll</i> . The scale automate 50ms/div and waveform state from the righ display (If the is already in the there will be a	e horizontal tically becomes d the arts scrolling t side of the e oscilloscope the Roll mode, no change).	Roll

Zooming the waveform horizontally



XY

(Fi)

EDGE FDC

93.3030kH

Zoom width

XY

esp

FDC

92.1656kHz

@ 2.5us

Viewing waveforms in the X-Y mode

Background	The X-Y mode compares the voltage of Channel 1 and Channel 2 waveforms in a single display. This mode is useful for observing the phase relationship between the two waveforms.			
Procedure	1. Connect the signals to Channel 1 (X-axis) and Channel 2 (Y-axis).			
	2. Make sure both Chann and 2 are activated.	nel 1 CH 1 CH 2		
	3. Press the Horizontal k	ey. (Environmentation)		
	4. Press XY. The display shows two waveforms in X- Y format; Channel 1 as X- axis, Channel 2 as Y-axis.			
Adjusting the X-Y mode waveform	Horizontal position	CH1 Position knob		
	Horizontal scale	CH1 Volts/Div knob		
	Vertical position	CH2 Position knob		
	Vertical scale	CH2 Volts/Div knob		
Example				



Horizontal Adjustment Menu

Background	The horizontal adjustment menu allows markers to be set at different times relative to the Horizontal position marker at 0 seconds. Each marker is linked to the mark directly before and after (in time). There can be up to 30 markers linked together.		
	1. Press the Horizontal menu key twice to enter the horizontal adjustment menu		
	2. Press <i>H Pos Adj</i> to toggle between coarse and fine adjustments.		
	3. Adjust the horizontal position with the horizontal position knob. ⊲⊘⊳		
Set marker	4. Press <i>Set/Clear</i> to create a marker at the current horizontal position. Set/Clear 180.0uS		
Delete marker	5. If there is already a marker at the current horizontal position press <i>Set/Clear</i> to delete the current marker.		
Reset horizontal position	 6. Press Reset to reset the horizontal position to 0 seconds when the trigger is running, or to the last position before the trigger was stopped. 		



Vertical View (Channel)

The Vertical view section describes how to set the vertical scale, position, bandwidth limitation, coupling mode, and attenuation.

Moving the	waveform position vertically		
Procedure	To move the waveform up or down, turn the vertical position \bigtriangledown		
Selecting th	e vertical scale		
Procedure	To change the vertical scale, turn the VOLTS/DIV knob; left (down) or right (up).		
Range	2mV/Div ~ 10V/Div, 1-2-5 increments		
Selecting th	e coupling mode		
Procedure	1. Press the Channel key.		
	2. Press <i>Coupling</i> repeatedly to select the coupling mode.		
Range	DC coupling mode. The whole portion (AC and DC) of the signal appears on the display.		
	Ground coupling mode. The display shows only the zero voltage level as a horizontal line. This mode is useful for measuring the signal amplitude with respect to the ground level.		

 \sim

AC coupling mode. Only the AC portion of the signal appears on the display. This mode is useful for observing AC waveforms mixed with DC components.

Expand Vertical Scale Center / Ground

Background Normally when the vertical scale is increased, the scaled image is centered from ground. However a signal with a voltage bias could be obscured when the vertical scale is increased. The Expand Center function expands the image from the center of the signal, rather than ground.

Expand Ground



Expand Center





Limiting the waveform bandwidth

Background	Bandwidth limitation puts the input signal into a 20MHz (-3dB) low-pass filter. This function is useful for cutting off high frequency noise to see the clear waveform shape.		
Procedure	1. Press the Channel key	CH 1	
	2. Press <i>BW Limit</i> to turn off the limitation. Whe turned on, the BW ind appears next to the Ch indicator in the display	h on or en licator hannel y. $\frac{BW Limit}{Off}$	
Example	BW Limit Off	BW Limit On	

Probe attenuation level and type

Background	The probe can be set to either voltage or current.
	A signal probe has an attenuation switch to lower the original DUT signal level to the oscilloscope input range, if necessary. The probe attenuation selection adjusts the vertical scale so that the voltage or current level on the display reflects the
	real value, not the attenuated level.
Drocoduro	1 Pross the Channel key CH1

Procedure 1. Press the Channel key.



	2. Press <i>F4</i> repeatedly to select voltage or current probes.		
	3. Use the variable knob to variable edit the voltage or current attenuation.		
	4. The voltage/current scale in the channel indicator changes accordingly. There is no change in the waveform shape.		
Range	0.1X~2000X (1-2-5 steps)		
<u>!</u>	Note: The attenuation factor adds no influence on the real signal; it only changes the voltage/current scale on the display.		

Trigger

The Trigger function configures the conditions by which the oscilloscope captures the incoming signals.

Trigger type				
Edge	Triggers when the signal crosses an amplitude threshold in either a positive or negative slope.			
Video	Extracts a sync pulse from a video format signal and triggers on a specific line or field.			
Pulse	Triggers matches	Triggers when the pulse width of the signal matches the trigger settings.		
Indicators	I	Edge/Pulse	Video	
	0 CH1 E 0 2.6521	DGE FDC ØkHz	CH1 VIDEO P NTSC C20Hz	
	(CH1, Ed DC coup	dge, Rising edge, Iling)	(CH1, Video, Positive polarity, NTSC standard)	
Trigger param	ieter			
Trigger source	CH1, 2	Channel 1, 2 in	put signals	
	Line	AC mains signal		
	Ext	External trigger input		
Trigger mode	Auto	The oscilloscope updates the input signal regardless of the trigger conditions (if there is no trigger event, the oscilloscope generates an internal trigger). Select this mode especially when viewing rolling waveforms at a slow timebase.		

The Auto trigger status appears in the upper right corner of the display.



	Single	The oscilloscope acquires the input signals once when a trigger event occurs, then stops acquiring. Pressing the Single key again will repeat the process.		
		The Single trigger status appears in the upper right corner of the display.		
		(Searching) (Triggered) Trig?◇ J™_ Trigger Stop ♦ J™_ Trigger		
	Normal	The oscilloscope acquires and updates the input signals only when a trigger event occurs.		
		The Normal trigger status appears in the upper right corner of the display.		
		(Searching) (Triggered)		
Holdoff	The holdoff function defines the waiting period before the GDS-1000A-U starts triggering again after a trigger point. The Holdoff function ensures a stable display.			
Video standard	NTSC	National Television System Committee		
(video trigger)	PAL	Phase Alternative by Line		
	SECAM	SEquential Couleur A Mémoire		
Sync polarity	fL_	Positive polarity		
(video trigger)		Negative polarity		
Video line	Selects	the trigger point in the video signal.		
(video trigger)	field	1 or 2		

G≝INSTEK

GDS-1000A-U	Series User	Manual
-------------	-------------	--------

line	1~263 for NTSC, 1~313 for PAL/	SECAM	
Sets the provident of the sets of the sets of the set o	Sets the pulse width (20ns ~ 10s) and the triggering condition.		
>	Longer than = Equal to		
<	Shorter than \neq Not equa	al to	
	Triggers on the rising edge.		
	Triggers on the falling edge.		
AC	Triggers only on AC compone	ent.	
DC	Triggers on AC+DC compone	nt.	
LF	Puts a high-pass filter and reje frequency below 50kHz.	Puts a high-pass filter and rejects the frequency below 50kHz.	
HF	Puts a low-pass filter and reject frequency above 50kHz.	ets the	
Rejects noise signals.			
Using the trigger level knob moves the trigger point up or down.			
oldoff			
The Holdoff function defines the waiting period before GDS-1000A-U starts triggering again after the trigger point. The holdoff function is especially useful for waveforms with two or more repetitive frequencies or periods that can be triggered.			
1. Press the Trigger menu key twice.		ND ND	
2. To se the V resolu horiz Rang	t the Holdoff time, use ariable knob. The ation depends on the ontal scale.	ABLE Long	
	line Sets the p condition > < AC DC LF HF Rejects n ^{LEVEL} oldoff The Hold before G the trigg useful fo frequence 1. Press twice 2. To se the V resolu horiz Rang	line 1~263 for NTSC, 1~313 for PAL/ Sets the pulse width (20ns ~ 10s) and the tricondition. > > Longer than = Equal to <	

Holdoff

40.0ns

Pressing *Set to Minimum* sets the Holdoff time to the minimum, 40ns.

Note: The holdoff function is automatically disabled when the waveform update mode is in Roll mode.

Configuring the edge trigger





Procedure	1.	Press the Trigger menu key.	MENU
	2.	Press <i>Type</i> repeatedly to select video trigger. The video trigger indicator appears at the bottom of the display.	Type Video
	3.	Press <i>Source</i> repeatedly to select the trigger source channel.	CH1
		Range Channel 1, 2	

G凹INSTEK



(Field 2), 1 ~ 313 (Field1)

Configuring the pulse width trigger

Procedure	1. Press the Trigger menu key.
	2. Press <i>Type</i> repeatedly to select pulse width trigger. The pulse width trigger indicator appears at the bottom of the display.
	3. Press <i>Source</i> repeatedly to select the trigger source. CH1
	Range Channel 1, 2, Ext

Mode

Auto

When <

20.0ns

Slope /

VARIABLE

SINGLE

4. Press *Mode* repeatedly to select the trigger mode, Auto or Normal. To select the Single trigger mode, press the Single key.



 Press When repeatedly to select the pulse condition. Then use the Variable knob to set the pulse width.

> Condition $>, <, =, \neq$ Width $20 \text{ns} \sim 10 \text{s}$

- 6. Press *Slope/Coupling* to set trigger slope and coupling.
- 7. Press *Slope* repeatedly to select the trigger slope, which also appears at the bottom of the display.





- Range Rising edge, falling edge
- 8. Press *Coupling* repeatedly to select the trigger coupling.

Range DC, AC

- 9. Press *Rejection* to select the frequency rejection mode.
 - Range LF, HF, Off



Rejection Off

10. Press <i>Noise Rej</i> to turn the noise rejection on or off.	Noise Rej Off
Range On, Off	
11. Press <i>Previous</i> menu to go back to the previous menu.	Previous Menu

Manually triggering the signal

<u>^</u>	Note: This section describes how to manually trigger the input signals when the oscilloscope does not capture them. This section applies to the Normal and Single trigger mode, since in the Auto trigger mode, the oscilloscope keeps updating the input signal regardless of the trigger conditions.		
To acquire the signal regardless of trigger conditions	To acquire the input signal regardless of the trigger condition, press the Force key. The oscilloscope captures the signals once.	FORCE	
In the Single trigger mode	Press the Single key to start waiting for the trigger condition. To break out of the Single mode, press the Run/Stop key. The trigger mode changes to the Normal mode.	Run/Stop	

Remote Control Interface

The Remote control interface section describes how to set up the USB interface for PC connection. Remote control command details are described in the GDS-1000A-U Programming Manual.

USB connection	PC	end	Type A, host		
	GDS-1000A-U end		Type B, slave		
	Speed		1.1/2.0 (full speed)		
Procedure	1.	Connect the US the USB slave p	B cable to 🔆		
	2.	When the PC asks for the USB driver, select dso_vpo.inf V1.06 or above for Windows XP/Vista/7(32/64 bit) which are downloadable from the GW website, <u>www.gwinstek.com</u> , GDS-1000A-U product corner.			
	3.	On the PC, acti as Hyper Term No., see the De WindowsXP, se Hardware tab.	vate a terminal application such inal. To check the COM port vice Manager in the PC. For elect Control panel \rightarrow System \rightarrow		
	4.	Run this query application. *idn? This command model number version in the f GW, GDS-1152	command via the terminal should return the manufacturer, , serial number, and firmware ollowing format. A-U, XXXXXXX, V1.00		
	5.	Configuring th complete. Refe the remote com	e command interface is r to the programming manual for mands and other details.		

System Settings

The system settings show the oscilloscope's system information and allow changing the language.

Viewing the system information

Procedure	1. Press the Utility key.
	2. Press <i>System Info</i> . The upper half of the display shows the following information.
	• Manufacturer • Model
	Serial number Firmware version
	Web address
	3. Press any other key to go back to the waveform display mode. More ►

Selecting the language

Parameter	Language selection differs according to the re to which the oscilloscope is shipped.		
	• English	•	Chinese (traditional)
	Chinese (simplified)	•	Japanese
	• Korean	•	French
	• German	•	Russian
	Portuguese	•	Italian
	• Polish	•	Spanish

Procedure	1.	Press the Utility key.	Utility	
	2.	Press <i>Language</i> repeatedly to select the language.	Language English	



The save function allows saving display images, waveform data, and panel settings into the oscilloscope's internal memory or to the front panel USB port. The recall function allows recalling the default factory settings, waveform data, and panel settings from the oscilloscope's internal memory or from USB.

File Structures

Three types of file are available: display image, waveform file, and panel settings.

Display image file format

Format	xxxx.bmp (Windows bitmap format)
Contents	The current display image in 234 x 320 pixels, color mode. The background color can be inverted (Ink saver function).

Waveform file format

Format	xxxx.csv (Comma-separated values format which can be opened in spreadsheet applications such as Microsoft Excel)
	Files can be saved as two different types of CSV formats. The GDS-1000A-U can recall any of the two formats

G≝INSTEK

	Detail	Contains the waveform amplitude and time of each point $(4k/1M/2M)$ relative to the trigger point.		
	Fast	Only contains the waveform amplitude data for each point (4k/1M/2M).		
Waveform type	CH1, 2	Input channel signal		
	Math	Math operation result (page 63)		
Storage location	Internal memory	The oscilloscope's internal memory, which can hold 15 waveforms.		
	External USB Flash drive	A USB flash drive (FAT or FAT32 format) can hold practically an unlimited number of waveforms.		
	Ref A, B	Two reference waveforms are used as a buffer to recall a waveform in the display. You have to save a waveform into internal memory or to USB, then copy the waveform into the reference waveform slot (A or B), and then recall the reference waveform into the display.		
Waveform Memory Depth	The memory depth is limited to 1 M points when both channels are activated or 2M points when only a single channel is activated. The signal must be triggered /stopped to have access to the full memory depth. Therefore when a signal is saved the waveform will be automatically stopped if it is not manually triggered /stopped first. There are a number of conditions when all of the available memory is not utilized due to a limited number of different sample rates. This can be caused by an un-triggered signal, or a time/div setting that is too fast to display all the points on screen.			
<u>Ì</u>	Note: 2M point memory lengths are only available for time bases slower than 10ns/div on a single channel, and 1 M point memory lengths are only available for time bases slower than 25ns/div on two channels.			
----------------------------------	--	----------------------	--	--
Waveform file contents: other	A waveform file also ind information.	cludes the following		
data	Memory Length	Trigger Level		
	• Source	• Probe		
	Vertical Units	Vertical Scale		
	Vertical Position	Horizontal Units		
	Horizontal Scale	Horizontal Position		
	Horizontal Mode	Sampling Period		
	• Firmware	• Time		
	• Mode	Waveform Data		

Setup file format

Format	xxxx.set (proprietary format) A setup file saves or recalls the following settings.				
Contents	Acquire	• mode			
	Cursor	source channelcursor location	• cursor on/off		
	Display	 dots/vectors grid type	 accumulation on/off 		
	Measure	• item			
	Utility	hardcopy typelanguageData Logging settings	ink saver on/offGo-Nogo settings		
	Horizontal	 display mode position	• scale		
	Trigger	 trigger type trigger mode video polarity pulse timing 	 source channel video standard video line slope/coupling 		
	Channel (vertical)	vertical scalecoupling modebandwidth limit on/off	 vertical position invert on/off voltage/current (probe) 		
	Math	 operation type vertical position FFT window	source channelunit/div		

Using the USB file utilities

Background	When a USB flash drive is inserted into the oscilloscope, file utilities (file deletion, folder creation and file/folder renaming) are available from the front panel.			
Procedure	1. Insert a USB flash drive into the front panel USB port.			
	 2. Press the Save/Recall key. Select any save or recall function. For example USB Destination in the Save image function. Save Image Destination USB 			
	3. Press <i>File Utilities</i> . The display shows the USB flash drive contents.			
	4. Use the Variable knob to move the cursor. Press <i>Select</i> to go into the folder or go back to the previous directory level.			
USB flash drive indicator	When a USB flash drive is inserted into the oscilloscope, an indicator appears at the right bottom corner of the display. (The USB flash drive shouldn't be removed when a file is saved or retrieved from USB).	e		
	U2R			

Creating a new folder / renaming a file or folder1. Move the cursor to t or folder location an New Folder or Renam file/folder name and character map will a on the display.		Move the cursor to the file or folder location and press <i>New Folder</i> or <i>Rename</i> . The file/folder name and the character map will appear on the display.	New Folder Rename	
	2.	Use the Variable knob to move the pointer to the characters. Press <i>Enter</i> <i>Character</i> to add a character or <i>Back Space</i> to delete a character.	VARIABLE Character Back Space	
	3.	When editing is complete, press <i>Save</i> . The new/renamed file or folder will be saved.	Save	
Deleting a folder or file	1.	Move the cursor to the folder or file location and press <i>Delete</i> . The message " <i>Press F4 again to confirm this process</i> " appears at the bottom of the display.	Delete	
	2.	If the file/folder still needs to be deleted, press <i>Delete</i> again to complete the deletion. To cancel the deletion, press any other key.	Delete	

Quick Save (HardCopy)

Background	The Hardcopy key works as a shortcut for saving display images, waveform data, and panel settings onto a USB flash drive card.				
	The Hardcop types of open (image, wave	by key can be config rations: save image eform, setup).	gured into two and save all		
	Using the Sa also save file options. For 115.	Save/Recall			
Functionalities	Save image Saves the current display imag (*.bmp) a USB flash drive.				
	Save all	Saves the followin flash drive. • Current display • Current system • Current wavefo	g items into a USB image (*.bmp) settings (*.set) rm data (*.csv)		
Procedure	1. Insert a USB flash drive into the front panel USB port.				
	2. Press the Utility key.				
	3. Press Hardcopy Menu.		Hardcopy Menu		
	4. Press Fun select Sav	ction repeatedly to e Image or Save All.	Function Save All		

Ink Saver

Off

- 5. To invert the color in the display image, press *Ink Saver*. This turns Ink Saver on or off.
- 6. If *Save Image* was selected, press *Mem Leng* repeatedly to select *USB Normal* or *USB 1M/2M*. USB Normal and USB 1M/2M sets the waveforms to a 4k and 1M/2M memory length when saving, respectively.

1M memory length is available when both CH1 and CH2 are active; 2M memory length is available when a single channel is active only.

7. Press the Hardcopy key. The file or folder will be saved to the root directory of the USB flash drive.





Save

This section describes how to save data using the Save/Recall menu.

File	type	/source	/destir	ation
1.110	57PC/	Jource	acstin	ation

ltom	Sourco	Destination
item	Source	Destination
Panel setup (xxxx.set)	• Panel settings	 Internal memory: S1 ~ S15
		• External memory: USB
Waveform data (xxxx.csv)	 Channel 1, 2 Math operation result	 Internal memory: W1 ~ W15 Reference waveform A, B
	• Reference waveform A, B	• External memory: USB
Display image (xxxx.bmp)	• Display image	• External memory: USB
Save All	 Display image (xxxx.bmp) 	• External memory: USB
	• Waveform data (xxxx.csv)	
	 Panel settings (xxxx.set) 	

Saving the panel settings

Procedure	1.	(For saving to USB flash drive) Insert the USB flash drive into the front panel USB port.		
	2.	Press the Sa twice to acc menu.	ave/Recall key less the Save	Save/Recall Save/Recall
	3.	Press Save S	Setup.	Save Setup
	4.	Press <i>Destination</i> repeatedly to select the saved location. Use the Variable knob to change the internal memory location (S1 ~ S15).		Destination Memory
		Memory	Internal memor	y, S1 ~ S15
		USB	USB, no practica amount of files. setup file will be directory.	al limitation for the When saved, the e placed in the root
	5.	Press <i>Save</i> t saving. Who message ap bottom of tl	o confirm en completed, a pears at the he display.	Save
	Nc	ote !	The file will not b power is turned o	be saved if the off or the USB flash

drive is removed before completion.

SAVE/RECALL

File utilities	Tc (cı an Fo	edit the USB (ceate/ delete/ d folders), pre r details, see p	drive contents rename files ss <i>File Utilities</i> . age 111.	File Utilities
Saving the way	vefo	orm		
Procedure	1.	(For saving to drive) Insert t drive into the USB port.	o USB flash the USB flash front panel	
	2.	Press the Save twice to acces menu.	e/Recall key ss the Save	Save/Recall
	3.	Press <i>Save Waveform</i> . Press <i>Source</i> . Use the Variable knob to select the source signal.		Save Waveform
	4.			Source VARIABLE
		CH1 ~ CH2	Channel 1 ~ 2	signal
		Math	Math operation	on result (page 63)
		RefA, B	Internally stor waveforms A,	ed reference B
	5.	Press <i>Destinat</i> to select the fi Use the Varia select the men	<i>tion</i> repeatedly ile destination. ble knob to mory location.	Destination Memory VARIABLE

	Memory	Internal memory, W1 ~ W15
	USB Normal	Save to the USB flash drive with a 4k waveform memory length.
	USB 1M	Save to the USB flash drive with a 1M waveform memory length. For 2 channel operation only.
	USB 2M	Save to the USB flash drive with a 2M waveform memory length. For single channel operation only.
	Ref	Internal reference waveform, A/B
	6. Press <i>Save</i> saving. W message a bottom of	to confirm hen completed, a ppears at the the display.
	Note	The file will not be saved if the power is turned off or the USB flash drive is removed from the USB port.
		It takes approximately 1 min to save a 2M waveform to the USB drive in fast mode. Detailed mode may take over 10 times longer depending on the speed of the USB flash drive.
File utilities	To edit the U (create/ delet and folders), For details, se	SB drive contents te/ rename files press <i>File Utilities</i> . File Utilities ee page 111.

Saving the display image

Background	Saving the display image can be used as a screen capture or it can be used as a reference waveform.				
Procedure	1. Insert the U into the fro port. (Imag be saved to	JSB flash drive ont panel USB ge files can only o USB)			
	2. Press the Sa twice to acc menu.	ave/Recall key cess the Save	Save/Recall		
	3. Press Save	Image.	Save Image		
	4. Press <i>Ink Sa</i> invert the k (on) or not	<i>aver</i> repeatedly to background color (off).	Ink Saver Off		
	5. Note: <i>Desti</i> USB. This c changed.	<i>ination</i> is set as cannot be	Destination USB		
	6. Press <i>Save</i> saving. Wh message ap bottom of t	to confirm nen completed, a opears at the che display.	Save		
	Note Note The file will not be saved if the power is turned off or the USB drive is removed before complete the transmission of transmission of the transmission of tr		e saved if the off or the USB flash before completion.		
File utilities	To edit the US (create/ delete and folders), p For details, see	B drive contents e/ rename files press <i>File Utilities</i> . e page 111.	File Utilities		

Saving all (panel settings, display image, waveform)

Procedure	1.	(For saving to U drive) Insert the drive into the fro USB port.	SB flash USB flash ont panel	
	2.	Press the Save/I twice to access the menu.	Recall key he Save	Save/Recall
	3.	Press <i>Save All</i> . This information will	he following be saved.	Save All
		Setup file (Axxxx.set)	Two types o the current p the last inter settings (one	f setups are saved: panel setting and rnally saved e of S1 ~ S15).
		Display image (Axxxx.bmp)	The current bitmap form	display image in nat.
		Waveform data (Axxxx.csv)	Two types o are saved: th channel data internally sa W1 ~ W15).	of waveform data the currently active a and the last aved data (one of
	4.	Press <i>Ink Saver</i> re invert the backg (on) or not (off) a display image.	epeatedly to round color for the	Ink Saver Off
	5.	Press Destination	l.	Destination USB 1M

USBSave to the USB flash drive with aNormal4k waveform memory length.

G≝INSTEK

	USB 1M	Save to the USB flash drive with a 1M waveform memory length. For 2 channel operation only.
	USB 2M	Save to the USB flash drive with a 2M waveform memory length. For single channel operation only.
	6. Press <i>Save</i> t saving. Wh message ap bottom of t	to confirm len completed, a opears at the he display.
	Note <u>!</u>	The file will not be saved if the power is turned off or the USB flash drive is removed from the USB port.
		It takes approximately 1 min to save a 2M waveform to the USB drive in fast mode. Detailed mode may take over 10 times longer depending on the speed of the USB flash drive.
	7. The current (*.SET) and a directory	t waveform(s) (*.CSV), setup file display image (*.BMP) are saved to (ALLXXXX).
File utilities	To edit the US (create/ delete and folders), p For details, see	B drive contents e/ rename files press <i>File Utilities</i> . File Utilities e page 111.

Recall

File type/source/destination

ltem	Source	Destination
Default panel setup	 Factory installed setting 	• Current front panel
Reference waveform	• Internal memory: A, B	• Current front panel
Panel setup (DSxxxx.set)	 Internal memory: S1 ~ S15 	• Current front panel
	• External memory: USB flash drive	
Waveform data (DSxxxx.csv)	 Internal memory: W1 ~ W15 	• Reference waveform A, B
	• External memory: USB flash drive	

Recalling the default panel settings

Procedure	1. Press the Save/Recall key. Save/Recall		
	2. Press <i>Default Setup</i> . The factory installed setting be recalled.	ne Default sg will Setup	
Setting contents	The following is the defa	ult panel setting contents.	
Acquisition	Mode: Normal		
Channel	Coupling: DC	Invert: Off	
	BW limit: Off	voltage: x1	
Cursor	Source: CH1	Horizontal: None	
	Vertical: None		
Display	Type: Vectors	Accumulate: Off	
	Graticule:		
Horizontal	Scale: 2.5us/Div	Mode: Main Timebase	
	H Pos Adj: Fine	Hor Pos: 0	
Math	Type: + (Add)	Channel: CH1+CH2	
	Position: 0.00 Div	Unit/Div: 2V	
Measure	Item: Vpp, Vavg, Frequency, Duty cycle, Rise Time		
Trigger	Type: Edge	Source: Channel1	
	Mode: Auto	Slope:	
	Coupling: DC	Rejection: Off	
	Noise Rejection: Off		
Utility	SaveImage, InkSaver On, 50% duty.	Probe squarewave 1kHz	

Recalling a reference waveform to the display

Procedure		The reference waveform mus advance. See page 117 for det	t be stored in ails.
	2.	Press the Save/Recall key.	Save/Recall
	3.	Press <i>Display Refs</i> . The reference waveform display menu appears.	Display Refs.
	4.	Select the reference waveform, <i>Ref A</i> or <i>Ref B</i> , and press it. The waveform appears on the display and the period and amplitude of the waveform appears in the menu.	Ref.A Off
	5.	To clear the waveform from the display, press <i>RefA/B</i> again.	Ref.A Off

Recalling panel settings

Procedure 1. (For recalling to USB) Insert the USB flash drive into the front panel USB port.

7	•	7
		J

2. Press the Save/Recall key.



G≝INSTEK

	3. Press Reca	ll Setup.	Recall Setup
	4. Press Sour select the f internal or memory. I knob to ch	<i>ce</i> repeatedly to file source, external Jse the Variable ange the memory.	Source Memory VARIABLE
	Memory	Internal memory	, S1 ~ S15
	USB	USB flash drive, setup file(s) must root directory to	DSXXXX.SET. The t be placed in the be recognized.
	5. Press <i>Recall</i> to confirm recalling. When completed, a message appears at the bottom of the display.		Recall
	Note	The file will not l power is turned o drive is removed	be recalled if the off or the USB flash before completion.
File utilities	To edit the USB drive contents (create/ delete/ rename files and folders), press <i>File Utilities</i> . For details, see page 111.		
Recalling a waveform			
Procedure	 (For recall the USB flat front pane 	ing to USB) Insert ash drive into the l USB port.	

2. Press the Save/Recall key.



3. Press Recall Waveform. The Recall display shows the available Waveform source and destination options. 4. Press *Source* repeatedly to Source select the file source, Memory internal memory or USB. VARIABLE Use the Variable knob to change the memory location $(W1 \sim W15)/DSXXXX.CSV.$ Memory Internal memory, W1 ~ W15 USB flash drive, USB DSXXXX.CSV. The waveform file(s) must be placed in the root directory to be loaded. 5. Press Destination. Use the Destination Variable knob to select the memory location. VARIABLE RefA, B Internally stored reference waveforms A, B 6. Press Recall to confirm Recall recalling. When completed, a message appears at the bottom of the display. The file will not be recalled if the Note power is turned off or the USB flash drive is removed before completion.

File utilities	To edit the USB drive contents (create/ delete/ rename files and folders), press <i>File Utilities</i> . For details, see page 111.		
Recall Image			
Background	Recall Image is useful for recalling reference images that would not be possible using the Recall Waveform function, such as in X-Y mode. Using the Recall Image function will superimpose the reference image on the screen.		
	Before recalling an image, an image must first be saved to USB, see page 119.		
	Reference off Berling Berling		
Procedure	1. Insert the USB flash drive into the front panel USB.		
	2. Press the Save/Recall key.		
	3. Press <i>Recall Image</i> . The display shows the available source and destination options.		

	 Use the Variable knob to choose a file name (DSXXXX.BMP). USB WARIABLE (DSXXXX.BMP). USB The image file must be placed in the root directory to be recognized.
	5. Press <i>Recall</i> to confirm recalling. When completed, a message appears at the bottom of the display.
	6. Press <i>Reference Image</i> to turn on / off the current image.
	Note The file will not be recalled if the power is turned off or the USB flash drive is removed before completion.
File utilities	To edit the USB drive contents (create/ delete/ rename files and folders), press <i>File Utilities</i> . For details, see page 111.

Two types of maintenance operations are available: calibrating the vertical resolution, and compensating the probe. Run these operations when using the oscilloscope in a new environment.

Vertical Resolution Calibration



- The Channel1 calibration will complete in less than 5 minutes.
- 8. When finished, connect the calibration signal to the Channel 2 input and repeat the procedure.

Ch1 calibration 1/3
•••••••00000



9. When the calibration is complete the display will go back to the previous state.

Probe Compensation

Procedure 1. Connect the probe between the Channel1 input and the probe compensation output (2Vp-p, 1kHz square wave) on the front panel. Set the probe voltage attenuation to x10.



- 2. Press the Utility key.
- Utility
- 3. Press ProbeComp.



GଆNSTEK

- 4. Press *Wavetype* repeatedly to select the standard square wave.
- Press the Autoset key. The compensation signal will appear in the display.
- 6. Press the Display key, then *Type* to select the vector waveform.



Wave Type





7. Turn the adjustment point on the probe until the signal edge becomes sharp.



FAQ

- The input signal does not appear in the display.
- I want to remove some contents from the display.
- The waveform does not update (frozen).
- The probe waveform is distorted.
- Autoset does not catch the signal well.
- I want to clean up the cluttered panel settings.
- The accuracy does not match the specifications.
- The oscilloscope will not allow a 2M waveform to be saved.

The input signal does not appear in the display.

Make sure you have activated the channel by pressing the CH key (page 47).

I want to remove some contents from the display.

To clear the math result, press the Math key again (page 63). To clear the cursor, press the Cursor key again (page 61). To clear the Help contents, press the Help key again (page 46). The waveform does not update (frozen).

Press the Run/Stop key to unfreeze the waveform. See page 50 for details. For trigger setting details, see page 96.

If this does not help, press the CH key. If the signal still does not appear, press the Autoset key.

The probe waveform is distorted.

You might need to compensate the probe. For details, see page 130. Note that the frequency accuracy and duty factor are not specified for probe compensation waveforms and therefore it should not be used for other reference purposes.

Autoset does not catch the signal well.

The Autoset function does not catch signals well under 30mV or 20Hz. Please operate the oscilloscope manually. See page 48 for details.

I want to clean up the cluttered panel settings.

Recall the default settings by pressing the Save/Recall key \rightarrow Default Setting. For default setting contents, see page 45.

The saved display image is too dark on the background.

Use the Inksaver function which reverses the background color. For details, see page 119.

The accuracy does not match the specifications.

Make sure the device is powered on for at least 30 minutes, within $+20^{\circ}C^{+}30^{\circ}C$. This is necessary to stabilize the unit to match the specification.

The oscilloscope will not allow a 2M waveform to be saved.

Make sure that only 1 channel is active. Make sure that the signal has been triggered and that the STOP or Single key has been pressed. Ensure the time base is slower than 10 ns/div. See page 107.

For more information, contact your local dealer or GWInstek at www.gwinstek.com / marketing@goodwill.com.tw.



Fuse Replacement

Procedure 1. Remove the power cord and remove the fuse socket using a minus driver.



2. Replace the fuse in the holder.



Ratings

T1A, 250V

GDS-1000A-U Series Specifications

The specifications apply when the oscilloscope is powered on for at least 30 minutes under $+20^{\circ}C^{+30}C$.

GDS-1072A-U	Bandwidth (-3dB)	DC coupling: DC ~ 70MHz AC coupling: 10Hz ~ 70MHz
	Bandwidth Limit	20MHz (-3dB)
	Trigger Sensitivity	0.5div or 5mV (DC ~ 25MHz)
		1.5div or 15mV (25MHz~70MHz)
	External Trigger	~ 50mV (DC~25MHz)
	Sensitivity	~ 100mV (25MHz~70MHz)
	Rise Time	< 5ns approx.
GDS-1102A-U	Bandwidth (-3dB)	DC coupling: DC ~ 100MHz
		AC coupling: 10Hz ~ 100MHz
	Bandwidth Limit	20MHz (-3dB)
	Trigger Sensitivity	0.5div or 5mV (DC ~ 25MHz)
		1.5div or 15mV (25MHz~100MHz)
	External Trigger	~ 50mV (DC~25MHz)
	Sensitivity	~ 100mV (25MHz~100MHz)
	Rise Time	< 3.5ns approx.
GDS-1152A-U	Bandwidth (-3dB)	DC coupling: DC ~ 150MHz
		AC coupling: 10Hz ~ 150MHz
	Bandwidth Limit	20MHz (-3dB)
	Trigger Sensitivity	0.5div or 5mV (DC ~ 25MHz)
		1.5div or 15mV (25MHz~150MHz)
	External Trigger	~ 50mV (DC~25MHz)
	Sensitivity	~ 100mV (25MHz~100MHz)
	Rise Time	< 2.3ns approx.

Model-specific specifications

Common specifications

Vertical	Sensitivity	2mV/div~10V/Div (1-2-5 increments)
	Accuracy	± 3 full scale
	Bandwidth	See model-specific specifications
	Rise Time	See model-specific specifications
	Input Coupling	AC, DC, Ground
	Input Impedance	1MΩ±2%, ~15pF
	Polarity	Normal, Invert
	Maximum Input	300V (DC+AC peak), CAT II
	Math Operation	+, –, ×, FFT, FFT rms
	Offset Range	2mV/div~50mV/div: ±0.4V
		100mV/div~500mV/div: ±4V
		1V/div~5V/div: ±40V
		10V/div : ±300V
Trigger	Sources	CH1, CH2, Line, EXT
	Modes	Auto, Normal, Single, TV, Edge, Pulse
	Coupling	AC, DC, LF rej, HF rej, Noise rej
	Sensitivity	See model-specific specifications
	Holdoff	40ns ~ 2.5s
External trigger	Range	DC: ±15V, AC: ±2V
	Sensitivity	See model-specific specifications
	Input Impedance	1MΩ±2%, ~15pF
	Maximum Input	300V (DC+AC peak), CATII
Horizontal	Range	1ns/div~50s/div, 1-2.5-5 increment
		Roll: 50ms/div – 50s/div
	Modes	Main, Window, Window Zoom, Roll, X-Y
	Accuracy	±0.01%
	Pre-Trigger	10 div maximum
	Post-Trigger	1000 div
X-Y Mode	X-Axis Input	Channel 1
	Y-Axis Input	Channel 2
	Phase Shift	±3° at 100kHz
Signal Acquisition	Real-Time	1G Sa/s maximum
	Equivalent	25G Sa/s maximum
	Vertical	8 bits
	Resolution	
	Record Length	Maximum; 2M points (1 channel), 1M
	A	points (2 channels)
	Acquisition	Normal, Peak Detect, Average
	Peak Detection	$100 \text{ s} (500 \text{ ms/div} \sim 50 \text{ s/div})$
	Average	2, 4, 8, 16, 32, 64, 128, 256

G≝INSTEK

GDS-1000A-U Series User Manual

Cursors and Measurement	Voltage	Vpp, Vamp, Vavg, Vrms, Vhi, Vlo, Vmax, Vmin, Rise Preshoot/ Overshoot, Fall Preshoot/ Overshoot	
	Time	Freq, Period, Rise Time, Fall Time, + Width, – Width, Duty Cycle	
	Delay	FRR, FRF, FFR, FFF, LRR, LRF, LFR, LFF	
	Cursors	Voltage difference (Δ V) and Time difference (Δ T) between cursors	
	Auto Counter	Resolution: 6 digits, Accuracy: ±2% Signal source: All available trigger source except the Video trigger	
Control Panel Function	Autoset	Automatically adjust Vertical Volt/div, Horizontal Time/div, and Trigger level	
	Save/Recall	Up to 15 sets of measurement conditions and waveforms	
Display	LCD	5.7 inch, TFT, brightness adjustable	
	Resolution (dots)	234 (Vertical) x 320 (Horizontal)	
	Graticule	8 x 10 divisions	
	Display Contrast	Adjustable	
Interface	USB Slave Connector	USB 2.0 full speed (CDC ACM)	
	USB Host connector	Image (BMP) and waveform data (CSV)	
Probe Compensation Signal	Frequency range	1kHz ~ 100kHz adjustable, 1kHz step	
	Duty cycle	5% ~ 95% adjustable, 5% step	
	Amplitude	2Vpp±3%	
Power Source	Line Voltage	100V~240V AC, 47Hz~63Hz	
	Power Consumption	18W, 40VA maximum	
	Fuse Rating	1A slow, 250V	
Operation	Ambient temperat	Ambient temperature 0 ~ 50°C	
Environment	Relative humidity:	\leq 80%, 40°C or below	
		≤45%, 41°C~50°C	
Storage	Storage Temperati	ure: -10°C~60°C. no condensation-	
Environment	Relative humidity	93% @ 40°C	
	Relative numberly	65% @ 41°C~60°C	
Dimensions	310(W) x 142(H) x	(140(D) mm	
Weight	Approx. 2.5kg		
	r F · · · · · · · · · · · · · · · · · ·		

Probe Specifications

GDS-1072A-U	Probe
-------------	-------

Applicable model & probe		GDS-1072A-U GTP-070B-4*
Position x 10	Attenuation	10
	Bandwidth	DC ~ 70MHz
	Input Resistance	10M Ω (when used with oscilloscopes which have 1M Ω input)
	Input Capacitance	14.5~17.5pF
	Maximum Input Voltage	≤600V DC +ACpk
	Compensation Range	10~35pF
Position x 1	Attenuation	1
	Bandwidth	DC ~ 10MHz
	Input Resistance	1M Ω (oscilloscope input resistance)
	Input Capacitance	85~115pF
	Maximum Input Voltage	≤200V DC +ACpk
Operating Cond.	Temperature	–10°C ~ 50°C
	Humidity	≤85% (Relative Humidity)
Net Weight	<55g	
Length	130cm±1.5cm	

GDS-1102A-U Probe

Applicable model & probe		GDS-1102A-U GTP-100B-4*
Position x 10	Attenuation	10
	Bandwidth	DC ~ 100MHz
	Input Resistance	10M Ω (when used with oscilloscopes which have 1M Ω input)
	Input Capacitance	14.5~17.5pF
	Maximum Input Voltage	≤600V DC +ACpk
	Compensation	5~30pF
	Range	
Position x 1	Attenuation	1
	Bandwidth	DC ~ 10MHz
	Input Resistance	$1M\Omega$ (oscilloscope input resistance)

GWINSTEK

	Input Capacitance	85~115pF
	Maximum Input	≤200V DC +ACpk
	Voltage	
Operating Cond.	Temperature	–10°C ~ 50°C
	Humidity	≤85% (Relative Humidity)
Net Weight	<55g	
Length	130cm±1.5cm	

GDS-1152A-U Probe

Applicable model & probe		GDS-1152A-U GTP-150B-4*
Position x 10	Attenuation	10
	Bandwidth	DC ~ 150MHz
	Input Resistance	10M Ω (when used with oscilloscopes which have 1M Ω input)
	Input Capacitance	14.5~17.5pF
	Maximum Input Voltage	≤600V DC +ACpk
	Compensation	5~30pF
	Range	
Position x 1	Attenuation	1
	Bandwidth	DC ~ 10MHz
	Input Resistance	1M Ω (oscilloscope input resistance)
	Input Capacitance	85~115pF
	Maximum Input	≤200V DC +ACpk
	voltage	
Operating Cond.	Temperature	–10°C ~ 50°C
	Humidity	≤85% (Relative Humidity)
Net Weight	<55g	
Length	130cm±1.5cm	

* Note: GW Instek reserves the right to change the probe model type (GTP-070B-4, GTP-100B-4, GTP-150B-4) at anytime without notice for probe model types of similar specification.

Dimensions





EC Declaration of Conformity

We

GOOD WILL INSTRUMENT CO., LTD.

No.7-1, Jhongsing Rd., Tucheng Dist., New Taipei City 236, Taiwan

GOOD WILL INSTRUMENT (SUZHOU) CO., LTD.

No. 69, Lushan Road, Suzhou New District Jiangsu, China

declares that the below mentioned product

GDS-1072A-U, GDS-1102A-U, GDS-1152A-U

Are herewith confirmed to comply with the requirements set out in the Council Directive on the Approximation of the Law of Member States relating to Electromagnetic Compatibility (2004/108/EC) & (2014/30/EU) and Low Voltage Equipment Directive (2006/95/EC) & (2014/35/EU). For the evaluation regarding the Electromagnetic Compatibility and Low Voltage Equipment Directive, the following standards were applied:

EN 61326-1 : EN 61326-2-1:	Electrical equipm laboratory use	nent for measurement, control and e — EMC requirements (2013)
Conducted and Radi EN 55011: 2009+A	ated Emissions 1: 2010	Electrostatic Discharge EN 61000-4-2: 2009
Current Harmonic EN 61000-3-2: 2014		Radiated Immunity EN 61000-4-3: 2008+A2 :2010
Voltage Fluctuation EN 61000-3-3: 2013		Electrical Fast Transients EN 61000-4-4: 2012
		Surge Immunity EN 61000-4-5: 2006
		Conducted Susceptibility EN 61000-4-6: 2014
		Power Frequency Magnetic Field EN 61000-4-8: 2010
		Voltage Dips/ Interrupts EN 61000-4-11: 2004

◎ EMC

© Safety

Low Voltage Equipment Directive 2006/95/EC & 2014/35/EU Safety Requirements EN 61010-1: 2010 (Third Edition) EN 61010-2-030: 2010 (First Edition)

NDEX

2M memory length limits	108
AC coupling	92
Accumulating waveform	83
Acquisition	78
menu tree	24
specification	137
Addition	64
Amplitude measure	55
Auto set	49
exception	50
specification	138
type	49
Auto trigger	96
Automatic measurement	58
menu tree	31
overview	55
specification	138
Automatic measurement gati	ng
	57
Average acquisition	79
Average voltage measure	56
Bandwidth limitation	94
Blackman window	64
Calibration	
menu tree	41
Calibration, vertical resolution	n
	129
Caution symbol	8
Channel.	47
fag	132
menu tree	24
Cleaning the instrument	10
Configure remote control	104
Coupling mode	91
menu tree	24
Cursor	61
faq	132

menu tree	25
specification	.138
Cycle time measure	56
Data logging	
menu tree	43
overview	74
run	77
setup	75
source	75
DC coupling	91
Declaration of conformity	.142
Default setup	.123
contents	45
menu tree	32
Delay measure	56
Delay mode	80
Delay Off	81
Delay On	80
Display	84
contrast setting	84
diagram	19
grid setting	84
menu tree	26
specification	. 138
Display image	
faq	. 133
file format	.107
recall menu tree	33
save	.119
save menu tree	35
Disposal instructions	11
Dot waveform	83
Duty cycle measure	56
Edge trigger	99
menu tree	38
EN61010	
measurement category	9
pollution degree	11

GWINSTEK

Environment	138
safety instructions	10
Equivalent time sampling	82
Expand Center	92
Expand Ground	92
External trigger	96
input terminal	17
Falling time measure	56
Faq	133
FFT	65
menu tree	30
overview	63, 64
File format	107
Firmware version	105
Flattop window	64
Force trigger	103
Frequency measure	56
Frequency rejection	98
Front panel diagram	15
Fuse replacement	135
safety instruction	10
Gated Automatic measurem	ents
	57
General purpose signal	53
General purpose signal Go-NoGo	53
General purpose signal Go-NoGo conditions	53 69
General purpose signal Go-NoGo conditions menu tree	53 69 40
General purpose signal Go-NoGo conditions menu tree overview	53 69 40 67
General purpose signal Go-NoGo conditions menu tree overview run	53 69 40 67 73
General purpose signal Go-NoGo conditions menu tree overview run source	53 69 40 67 73 68
General purpose signal Go-NoGo conditions menu tree overview run source template	53 69 67 67 68 69
General purpose signal Go-NoGo conditions menu tree overview run source template when	53 69 40 67 67 68 68 69
General purpose signal Go-NoGo conditions menu tree overview run source template when Ground	53 69 67 67 68 68 69 68
General purpose signal Go-NoGo conditions menu tree overview run source template when Ground coupling	53 69 67 67 68 69 68 69
General purpose signal Go-NoGo conditions menu tree overview run source template when Ground coupling symbol	53 69 67 67 68 69 68 69 68
General purpose signal Go-NoGo conditions menu tree overview run. source template when Ground coupling symbol terminal	53 69 67 73 68 69 68 91 8 91
General purpose signal Go-NoGo conditions menu tree overview run source template when Ground coupling symbol terminal Hanning window	53 69 40 67 73 68 69 68 91 8 91 8 17 64
General purpose signal Go-NoGo conditions menu tree overview run source template when Ground coupling symbol terminal Hanning window Hardcopy	53 69 67 67 68 68 69 68 91 68 91
General purpose signal Go-NoGo conditions menu tree overview run source template when Ground coupling symbol terminal Hanning window Hardcopy Hardcopy - Save All	53 69 67 67 68 68 69 68 69 68 91 8 17 64 113
General purpose signal Go-NoGo conditions	53 69 67 67 68 69 68 91 8 17 64 113 41
General purpose signal Go-NoGo conditions	53 69 67 67 68 69 68 91 8 17 64 113 41
General purpose signal Go-NoGo conditions	53 69 67 67 68 69 68 91 64 113 64 113 41 42, 44
General purpose signal Go-NoGo conditions	53 69 67 67 68 69 68 91 64 113 41 42, 44 46 41
General purpose signal Go-NoGo conditions	53 69 67 73 68 91 68 91 64 113 41 42, 44 42, 44 46 132 55
General purpose signal Go-NoGo conditions	53 69 67 73 68 69 68 91 64 113 41 42, 44 46 132 55

GDS-1000A-U Series User Manual

Horizontal85
basic operation51
cursor operation61
menu tree27
position85
scale
specification137
IEC 1010-1 139, 140
Image
recall127
Ink saver
in hardcopy114
in save all 120
Input frequency indicator 19
Invert waveform
Language selection 105
List of features13
Low voltage measure
Math
fag
menu tree
overview 63
Measurement47
Memory Length
5 0
faq 134
faq134 Model caomparison13
faq134 Model caomparison13 Multiplication
faq
faq
faq
faq134Model caomparison13Multiplication64Negative peak measure55Noise rejection98Normal acquisition78Normal trigger97NTSC97Operating environment138Overshoot voltage measure56PAL97Peak detect acquisition79
faq134Model caomparison13Multiplication64Negative peak measure55Noise rejection98Normal acquisition78Normal trigger97NTSC97Operating environment138Overshoot voltage measure56PAL97Peak detect acquisition79Peak to peak measure55
faq134Model caomparison13Multiplication64Negative peak measure55Noise rejection98Normal acquisition78Normal trigger97NTSC97Operating environment138Overshoot voltage measure56PAL97Peak detect acquisition79Peak to peak measure55Peak voltage measure55
faq134Model caomparison13Multiplication64Negative peak measure55Noise rejection98Normal acquisition78Normal trigger97NTSC97Operating environment138Overshoot voltage measure56PAL97Peak detect acquisition79Peak to peak measure55Peak voltage measure55Power on/off
faq134Model caomparison13Multiplication64Negative peak measure55Noise rejection98Normal acquisition78Normal trigger97NTSC97Operating environment138Overshoot voltage measure56PAL97Peak detect acquisition79Peak to peak measure55Peak voltage measure55Power on/off55Power on/off10
faq134Model caomparison13Multiplication64Negative peak measure55Noise rejection98Normal acquisition78Normal trigger97NTSC97Operating environment138Overshoot voltage measure56PAL97Peak detect acquisition79Peak to peak measure55Peak voltage measure55Power on/offsafety instructionswitch overview18
faq134Model caomparison13Multiplication64Negative peak measure55Noise rejection98Normal acquisition78Normal trigger97NTSC97Operating environment138Overshoot voltage measure56PAL97Peak detect acquisition79Peak to peak measure55Peak voltage measure55Power on/offsafety instructionswitch overview18Preshoot voltage measure56
faq134Model caomparison13Multiplication64Negative peak measure55Noise rejection98Normal acquisition78Normal trigger97NTSC97Operating environment138Overshoot voltage measure56PAL97Peak detect acquisition79Peak to peak measure55Peak voltage measure55Power on/offsafety instructionsafety instruction10switch overview18Preshoot voltage measure56Probe130
faq134Model caomparison13Multiplication64Negative peak measure55Noise rejection98Normal acquisition78Normal trigger97NTSC97Operating environment138Overshoot voltage measure56PAL97Peak detect acquisition79Peak to peak measure55Power on/off55Power on/off10switch overview18Preshoot voltage measure56Probe130attenuation level94
faq134Model caomparison13Multiplication64Negative peak measure55Noise rejection98Normal acquisition78Normal trigger97NTSC97Operating environment138Overshoot voltage measure56PAL97Peak detect acquisition79Peak to peak measure55Power on/off55Power on/off10switch overview18Preshoot voltage measure56Probe130attenuation level94attenuation menu tree24
GWINSTEK

compensation signal overview	53
faq	.133
peak detect demonstration	79
Pulse time measure	56
Pulse width trigger	101
condition	98
menu tree	38
Real time sampling	82
Rear panel diagram	18
Recall	122
default setup	.123
image	.127
menu tree	32
reference waveform	.124
setup	.124
waveform	.125
Rectangular window	64
Reference waveform	
menu tree	34
recall	124
Remote control interface	104
Rising time measure	56
Roll mode	86
Root mean square measure	56
Run/stop	50
faq	.133
Save	115
display image	.119
menu tree	32
setup	.116
specification	.138
waveform	117
Save all	120
menu tree	36
SECAM	97
Security lock slot	18
Serial number	105
Service operation	
about disassembly	9
contact	.134
Setting the handle	20
Setting up the oscilloscope	20
Setup	
default contents	45
file format	.110
how to save	
recall	.124

recall menu tree32
save menu tree34
Single trigger103
Single trigger mode
Specifications
faq134
Subtraction
System information105
Timebase indicator85
Trigger
coupling
edge
force
indicator96
level knob98
menu tree
parameter96
pulse width101
specification137
status indicator19
video100
UK power cord12
USB
file operation111
file utilities menu tree36
Utility
key overview16
menu tree40
Vector waveform83
Vertical91
basic operation52
cursor operation62
position
resolution calibration
scale
specification
Video line
Video trigger100
menu tree
Warning symbol8
Waveform
expand waveform
file format107
Invert waveform
memory deptn
recall menu tree 22
roll mode 86

INDEX

G≝INSTEK

GDS-1000A-U Series User Manual

save	117
save menu tree	35
x-y mode	88, 89
zoom mode	87
Waveform accumulation	83

X-Y mode	. 88, 89
specification	137
Zoom waveform	